


# HP ProCurve Switch 6400cl series

## Installation and Getting Started Guide



[www.hp.com/go/hpprocurve](http://www.hp.com/go/hpprocurve)



---

# ProCurve Switch 6400cl Series

---

## Installation and Getting Started Guide

© Copyright 2005 Hewlett-Packard Development Company, L.P. The information contained herein is subject to change without notice.

This document contains proprietary information, which is protected by copyright. No part of this document may be photocopied, reproduced, or translated into another language without prior written consent of Hewlett-Packard.

## Publication Number

5990-8844  
January 2005

## Applicable Products

HP ProCurve Switch 10-GbE CX4 6400cl-6XG (J8433A)  
HP ProCurve Switch 10-GbE X2 6410cl-6XG (J8474A)  
HP ProCurve 600 Redundant and External  
Power Supply (J8168A)  
HP ProCurve 10-GbE X2 SR-SC Xcvr (J8436A)  
HP ProCurve 10-GbE X2 LR-SC Xcvr (J8437A)  
HP ProCurve 10-GbE CX4 Media Converter (J8439A)  
HP ProCurve 10-GbE X2 CX4 Xcvr (J8440A)  
HP ProCurve 10-GbE Copper Module (J8434A)  
HP ProCurve 10-GbE Media Flex Module (J8435A)

## Trademark Credits

Windows NT®, Windows®, and MS Windows® are US registered trademarks of Microsoft Corporation. Adobe® and Acrobat® are trademarks of Adobe Systems Incorporated. Java™ is a US trademark of Sun Microsystems, Inc.

## Disclaimer

HEWLETT-PACKARD COMPANY MAKES NO WARRANTY OF ANY KIND WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Hewlett-Packard shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Hewlett-Packard assumes no responsibility for the use or reliability of its software on equipment that is not furnished by Hewlett-Packard.

## Warranty

See the Customer Support/Warranty booklet included with the product.

A copy of the specific warranty terms applicable to your Hewlett-Packard products and replacement parts can be obtained from your HP Sales and Service Office or authorized dealer.

---

## Safety

Before installing and operating these products, please read the “Installation Precautions” in chapter 2, “Installing the Switch”, and the safety statements in appendix B, “Safety and EMC Regulatory Statements”.

---

---

# Contents

## Introducing the Switch

|                                         |      |
|-----------------------------------------|------|
| Front of the Switch .....               | 1-3  |
| Console Port .....                      | 1-4  |
| Network Ports .....                     | 1-4  |
| Reset Button .....                      | 1-4  |
| Clear Button .....                      | 1-4  |
| LEDs .....                              | 1-5  |
| Location of Status Indicator LEDs ..... | 1-7  |
| Expansion cl Module LEDs .....          | 1-8  |
| Back of the Switch .....                | 1-9  |
| cl Module Slot .....                    | 1-9  |
| RPS Input Port .....                    | 1-9  |
| Power Connector .....                   | 1-9  |
| Switch Features .....                   | 1-10 |

## Installing the Switch

|                                                      |      |
|------------------------------------------------------|------|
| Included Parts .....                                 | 2-1  |
| Installation Procedures .....                        | 2-3  |
| Summary .....                                        | 2-3  |
| Installation Precautions: .....                      | 2-4  |
| 1. Prepare the Installation Site .....               | 2-5  |
| 2. (Optional) Install or Remove a cl Module .....    | 2-7  |
| 3. (Optional) Install or Remove a Transceiver .....  | 2-8  |
| To remove the transceiver: .....                     | 2-8  |
| 4. Verify the Switch Passes Self Test .....          | 2-9  |
| LED Behavior: .....                                  | 2-10 |
| 5. Mount the Switch .....                            | 2-11 |
| Rack or Cabinet Mounting .....                       | 2-11 |
| Rack Mounting the Switch 6400cl Series Devices ..... | 2-12 |
| Horizontal Surface Mounting .....                    | 2-13 |
| 6. Connect the Switch to a Power Source .....        | 2-13 |

|                                                                    |      |
|--------------------------------------------------------------------|------|
| 7. Connect the Network Cables .....                                | 2-14 |
| Connecting a fiber cable .....                                     | 2-14 |
| Connecting a copper cable .....                                    | 2-14 |
| 8. (Optional) Connect a Redundant Power Supply to the Switch ..... | 2-15 |
| 9. (Optional) Connect a Console to the Switch .....                | 2-18 |
| Terminal Configuration .....                                       | 2-18 |
| Direct Console Access .....                                        | 2-19 |
| Sample Network Topologies .....                                    | 2-20 |
| Three Tier Model .....                                             | 2-20 |
| Remote Campus .....                                                | 2-21 |
| Flexible Stacking .....                                            | 2-22 |
| High performance stack .....                                       | 2-22 |
| Resiliency Using 6400cl Series as a meshed Cluster .....           | 2-23 |

## **Getting Started With Switch Configuration**

|                                                         |     |
|---------------------------------------------------------|-----|
| Recommended Minimal Configuration .....                 | 3-1 |
| Using the Console Setup Screen .....                    | 3-2 |
| Where to Go From Here .....                             | 3-4 |
| To Recover from a Lost Manager Password: .....          | 3-4 |
| Using the IP Address for Remote Switch Management ..... | 3-5 |
| Starting a Telnet Session .....                         | 3-5 |
| Starting a Web Browser Session .....                    | 3-5 |

## **Troubleshooting**

|                                                       |      |
|-------------------------------------------------------|------|
| Basic Troubleshooting Tips .....                      | 4-1  |
| Diagnosing with the LEDs .....                        | 4-3  |
| Proactive Networking .....                            | 4-6  |
| Hardware Diagnostic Tests .....                       | 4-7  |
| Testing the Switch by Resetting It .....              | 4-7  |
| Checking the Switch LEDs .....                        | 4-7  |
| Checking Console Messages .....                       | 4-7  |
| Testing Switch-to-Device Network Communications ..... | 4-8  |
| Testing End-to-End Network Communications .....       | 4-8  |
| Restoring the Factory Default Configuration .....     | 4-9  |
| Downloading New Switch Software .....                 | 4-10 |

|                                    |      |
|------------------------------------|------|
| HP Customer Support Services ..... | 4-11 |
| Before Calling Support .....       | 4-11 |

## **Specifications**

|                     |     |
|---------------------|-----|
| Physical .....      | A-1 |
| Electrical .....    | A-1 |
| Environmental ..... | A-1 |
| Acoustic .....      | A-2 |
| Connectors .....    | A-2 |
| Safety .....        | A-2 |
| Lasers .....        | A-2 |

## **Safety and EMC Regulatory Statements**

|                                           |      |
|-------------------------------------------|------|
| Safety Information .....                  | B-1  |
| Informations concernant la sécurité ..... | B-2  |
| Hinweise zur Sicherheit .....             | B-3  |
| Considerazioni sulla sicurezza .....      | B-4  |
| Consideraciones sobre seguridad .....     | B-5  |
| Safety Information (Japan) .....          | B-6  |
| Safety Information (China) .....          | B-7  |
| EMC Regulatory Statements .....           | B-8  |
| U.S.A. ....                               | B-8  |
| Canada .....                              | B-8  |
| Australia/New Zealand .....               | B-8  |
| Japan .....                               | B-8  |
| Korea .....                               | B-9  |
| Taiwan .....                              | B-9  |
| European Community .....                  | B-10 |

## **Index**



# Introducing the Switch

The HP ProCurve Switches 6400cl are multiport switches that can be used to build high-performance switched workgroup networks. These switches are store-and-forward devices offering low latency for high-speed networking.

## HP ProCurve Switch 10-Gig CX4 6400cl-6XG (J8433A)



## HP ProCurve Switch 10-Gig 6410cl-6XG (J8474A)



Throughout this manual, this switch will be abbreviated as the Switch 6400cl-6XG or Switch 6410cl-6XG and collectively as the Switch 6400cl Series devices.

The Switch 6400cl-6XG and Switch 6410cl-6XG have respectively, six fixed copper or six flexible media X2 transceiver slots, and one slot is provided in the back of the device to support a two port 10-Gigabit per second Ethernet (10-GbE) module to provide box connectivity to other switch boxes, to a 10-GbE concentrator or to any Ethernet compatible uplink.



The Switch 6400cl Series devices can be connected to an HP ProCurve 600 Redundant and External Power supply (RPS/EPS (J8168A)) and receive full redundant power if the internal power supply in the switch fails. The RPS/EPS unit will immediately provide all the power necessary to keep the switch running.

These switches are designed to be used primarily in a high-density wiring closet or in a data center. These switches can directly connect computers and servers to provide dedicated bandwidth to those devices, and can build a switched network infrastructure by connecting the switch to other switches and routers that support 10-GbE. In addition, the Switch 6400cl Series devices offer full network management capabilities.

This chapter describes the Switch 6400cl Series devices, including:

- Front and back of the switches
- Switch features

# Front of the Switch



## Console Port

This port is used to connect a console to the switch by using the serial cable supplied with the switch. This connection is described under “Connect a Console to the Switch” in chapter 2, “Installing the Switch.” The console can be a PC or workstation running a VT-100 terminal emulator, or a VT-100 terminal. The console port is located on the front of both 6400cl devices.

## Network Ports

- Six fixed copper ports or six flexible media X2 transceiver 10-GbE slots.
- One, 10-GbE expansion slot. These switches provide a single slot in the back of the device that can accept a 2 by 10-GbE transceiver module. There are two types of modules:
  - 10-GbE Copper cl Module (J8434A) - provides two CX4 fixed copper ports
  - 10-GbE Media-Flex cl Module (J8435A) - provides two flexible media slots

For more information see the *HP ProCurve Switch cl Modules Installation Guide*.

## Reset Button

This button is used to reset the switch while it is powered on. This action clears any temporary error conditions that may have occurred and executes the switch self test.

## Clear Button

This button is used for these purposes:

- **Deleting Passwords** - When pressed by itself for at least one second, the button deletes any switch console access passwords that you may have configured. Use this feature if you have misplaced the password and need console access.

*This button is provided for your convenience, but its presence means that if you are concerned with the security of the switch configuration and operation, you should make sure the switch is installed in a secure location, such as a locked wiring closet.*

*The Clear button can also be disabled using a CLI command, see your “Access Security Guide, the Configuring Front-Panel Security section,” which is on the Documentation CD-ROM that came with your switch.*

- **Restoring Factory Default Configuration** - When pressed with the Reset button in a specific pattern, any configuration changes you may have made through the switch console, the web browser interface, and SNMP management are removed, and the factory default configuration is restored to the switch. For the specific method to restore the factory default configuration, see [“Restoring the Factory Default Configuration” on page 9](#), in chapter 4, “Troubleshooting” of this manual.

LEDs

Table 1-1. Switch LEDs



| Switch LEDs                                       | State                                                            | Meaning                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|---------------------------------------------------|------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Power (green)                                     | On<br>Off                                                        | The switch is receiving power.<br>The switch is NOT receiving power.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| Fault (orange)                                    | Off<br>Blinking*<br>On                                           | The normal state; indicates there are no fault conditions on the switch.<br>A fault has occurred on the switch, one of the switch ports, or the fan. The Status LED for the component with the fault will blink simultaneously.<br>On briefly after the switch is powered on or reset, at the beginning of switch self test. If this LED is on for a prolonged time, the switch has encountered a fatal hardware failure, or has failed its self test. See chapter 4, “Troubleshooting” for more information.                                                                                              |
| Port LEDs (green – overlaid with the port number) | Displays port link information and network activity information. |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| (2 green LEDs)                                    | Link                                                             | Indicates the port LEDs are displaying link information: <ul style="list-style-type: none"><li>• if the port LED is on, the port is enabled and receiving a link indication from the connected device.</li><li>• if the port LED is off, the port has no active network cable connected, or is not receiving link beat or sufficient light. Otherwise, the port may have been disabled through the switch console, the web browser interface, or HP ProCurve Manager.</li><li>• if the port LED is blinking* simultaneously with the Fault LED, the corresponding port has failed its self test.</li></ul> |
|                                                   | Activity                                                         | Indicates the port LEDs are displaying network activity information.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| Mdl (Module Status, green)                        | On                                                               | Expansion module is plugged into expansion slot and operating correctly                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|                                                   | Blinking                                                         | Expansion module is plugged into expansion slot but has experienced a fault                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|                                                   | Off                                                              | Expansion module is not plugged into expansion slot                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |

| Switch LEDs                                                                       | State     | Meaning                                                                                                                                                                                                                                                                                                       |
|-----------------------------------------------------------------------------------|-----------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| RPS Status<br>(green)                                                             | On        | Normal operation. RPS is connected and operating correctly. RPS could be powering the unit - see table below.                                                                                                                                                                                                 |
|                                                                                   | Blinking  | RPS is connected but has experienced a fault.                                                                                                                                                                                                                                                                 |
|                                                                                   | Off       | RPS is not connected or is not powered.                                                                                                                                                                                                                                                                       |
| Fan Status<br>(green)                                                             | On        | Normal operation, all fans are ok.                                                                                                                                                                                                                                                                            |
|                                                                                   | Blinking* | One of the unit's fans has failed. The switch Fault LED will be blinking simultaneously.                                                                                                                                                                                                                      |
| Test<br>(green)                                                                   | Off       | The normal operational state; the switch is not undergoing self test.                                                                                                                                                                                                                                         |
|                                                                                   | On        | The switch self test and initialization are in progress after the switch has been power cycled or reset. The switch is not operational until this LED goes off. The Self Test LED also comes on briefly when you "hot swap" a mini-GBIC into the switch; the mini-GBIC is self tested when it is hot swapped. |
|                                                                                   | Blinking* | A component of the switch has failed its self test and the switch Fault LED will blink simultaneously.                                                                                                                                                                                                        |
| Auxiliary<br>(green)                                                              | On        | Port is in use                                                                                                                                                                                                                                                                                                |
|                                                                                   | Off       | Port is not in use                                                                                                                                                                                                                                                                                            |
| * The blinking behavior is an on/off cycle once every 1.6 seconds, approximately. |           |                                                                                                                                                                                                                                                                                                               |

**Table 1-2. RPS LED Behavior**

| RPS modes | This table describes the behavior of the RPS LED associated with HP 600 RPS/EPS operation. (Power, RPS/EPS, Fault) |           |                                                                                                                                                                                                                                                                                                   |
|-----------|--------------------------------------------------------------------------------------------------------------------|-----------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Power LED | RPS LED                                                                                                            | Fault LED | Description                                                                                                                                                                                                                                                                                       |
| On        | Off                                                                                                                | Off       | Normal operation. HP 600 RPS/EPS is not connected or not powered.                                                                                                                                                                                                                                 |
| On        | On                                                                                                                 | Off       | Normal operation. HP 600 RPS/EPS is available.                                                                                                                                                                                                                                                    |
| On        | On/Off                                                                                                             | Blinking  | Unit has experienced a fault and another LED will be blinking to determine fault.                                                                                                                                                                                                                 |
| Off       | On                                                                                                                 | Blinking  | HP 600 RPS/EPS is running the switch in failover mode. No AC power to the unit, or the internal power supply has failed.                                                                                                                                                                          |
| Off       | Off                                                                                                                | Off       | Unit is un-powered by AC input line and the external HP 600 RPS/EPS                                                                                                                                                                                                                               |
| On        | Blinking                                                                                                           | Blinking  | The HP 600 RPS/EPS unit has experienced a fault.                                                                                                                                                                                                                                                  |
| On        | Blinking                                                                                                           | Off       | The HP 600 RPS/EPS unit is unavailable to power the Switch in event of an internal power supply failure. The HP 600 RPS/EPS is designed to provide power to one of its connected switch devices at a time. The Power Status LED on the HP 600 RPS/EPS unit will also be blinking for this device. |

## Location of Status Indicator LEDs



- If the Link indicator LED is lit, each port LED displays link information for the associated port
- If the Activity indicator LED is lit, each port LED displays activity information for the associated port—it flickers as network traffic is received and transmitted through the port.

## Expansion c1 Module LEDs

Expansion c1 Module LEDs refer to the LEDs specific to the expansion module. These LEDs are located on the physical expansion module bulkhead. These LEDs are only viewable in the rear of the Switch on the Expansion Module itself.

**Table 1-3. Expansion c1 Module LEDs**


| Name                             | Color  | Mode     | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|----------------------------------|--------|----------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Expansion Module LEDs per module |        |          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| Module Power<br>(ports A & B)    | Green  | On       | Expansion c1 module is plugged into expansion slot and operating correctly                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|                                  |        | Off      | Expansion c1 module's power has been turned OFF, and the card can be removed from the box if necessary.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| Module Fault<br>(ports A & B)    | Orange | On       | Expansion c1 module is plugged into expansion slot but has experienced a fault                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| Expansion Module LEDs per port   |        |          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| Link                             | Green  | On       | Indicates the port LEDs are displaying link information: <ul style="list-style-type: none"><li>if the port LED is on, the port is enabled and receiving a link indication from the connected device.</li><li>if the port LED is off, the port has no active network cable connected, or is not receiving link beat or sufficient light. Otherwise, the port may have been disabled through the switch console, the web browser interface, or HP ProCurve Manager.</li><li>if the port LED is blinking* simultaneously with the Fault LED, the corresponding port has failed its self test.</li></ul> |
|                                  |        | Off      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|                                  |        | Blinking |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| Activity                         | Green  | On       | Indicates the port LEDs are displaying network activity information.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |

**Caution**

It is recommended the power to the switch be removed before inserting or extracting the expansion module. If the expansion module is inserted or removed with the switch powered on, a reset will occur. Only install or remove these modules during scheduled downtime.

## Back of the Switch

The back of both 6400cl Series switches look the same.



### cl Module Slot

This switch supports one of two types of cl modules:

- 10-GbE Copper cl Module (J8434A) - provides two CX4 fixed copper ports
- 10-GbE Media-Flex cl Module (J8435A) - provides two flexible media slots that support a number of different transceivers. See the *HP ProCurve Switch cl Modules Installation Guide* for more information on supported transceivers.

### RPS Input Port

The Switch 6400cl Series supports connectivity to a redundant power supply. The “HP ProCurve 600 Redundant and External Power Supply (RPS/EPS) (J8168A) is an accessory product for the Switch 6400cl Series devices. The RPS/EPS provides redundant power to any one of up to six switch products, to back up the power supply in the switch in case of loss of AC power. See Step 8 of the installation instructions [page 2-15](#) for more information.

### Power Connector

The Switch 6400cl Series devices do not have a power switch; they are powered on when connected to an active AC power source. These switches automatically adjust to any voltage between 100–240 volts and either 50 or 60 Hz. There are no voltage range settings required.

---

## Switch Features

The features of the Switch 6400cl Series devices include:

- The Switch 6400cl-6XG and Switch 6410cl-6XG have respectively, six fixed copper or six flexible media X2 transceiver slots, to support 10-GbE connectivity to other switch boxes, to a 10-GbE concentrator or to any Ethernet compatible uplink.
- One slot (optional cl module slot) is provided in the back of the device to support a series of transceivers to provide box connectivity to other switch boxes, to a 10-GbE concentrator or to any Ethernet compatible uplink.
- One auxiliary (USB) port is provided.
- The Switch 6400cl Series devices can be connected to an HP ProCurve RPS/EPS (J8168A) and receive full redundant power if the internal power supply in the switch fails. The RPS/EPS unit will immediately provide all the power necessary to keep the switch running.
- Plug-and-play networking—all ports are enabled—just connect the network cables to active network devices and your switched network is operational.
- Easy management of the switch through several available interfaces:
  - **console interface**—a full featured, easy to use, VT-100 terminal interface that is especially good for out-of-band switch management or for Telnet access to the switch.
  - **web browser interface**—an easy to use built-in graphical interface that can be accessed from common web browsers.
  - **HP ProCurve Manager**—an SNMP-based, graphical network management tool that you can use to manage your entire network. This product is included with your new switch.
- Support for the Spanning Tree Protocol to eliminate network loops.
- Support for IEEE 802.1Q-compatible VLANs so you can divide the attached end nodes into logical groupings that fit your business needs.
- Support for many advanced features to enhance network performance—for a description, see the *Management and Configuration Guide*, which is on the Documentation CD-ROM that is included with your switch.
- Download of new switch software for product enhancements or bug fixes.

# Installing the Switch

---

The HP ProCurve Switch 6400cl Series devices come with an accessory kit that includes the brackets for mounting the switch in a standard 19-inch telco rack, in an equipment cabinet, and with rubber feet that can be attached so the switch can be securely located on a horizontal surface. The brackets are designed to allow mounting the switch in a variety of locations and orientations. This chapter shows how to install the switch.

---

## Included Parts

The Switch 6400cl Series devices have the following components shipped with them:

- *HP ProCurve Switch 6400cl Series Installation and Getting Started Guide*, this manual
- *HP ProCurve Product Documentation CD ROM*  
(contains PDF file copies of the documentation for the Switch 6400cl Series devices, including the *Management and Configuration Guide*, and for most other HP ProCurve switches)
- *HP ProCurve Manager* - CD ROM and booklet
- *Read Me First*
- Customer Support/Warranty booklet
- Console cable
- Accessory kit (5069-5705)
  - two mounting brackets
  - eight 8-mm M4 screws to attach the mounting brackets to the switch
  - four 5/8-inch number 12-24 screws to attach the switch to a rack
  - four rubber feet

■ Power cord, one of the following:

|                                    |           |
|------------------------------------|-----------|
| Australia/New Zealand              | 8120-6803 |
| China                              | 8120-8377 |
| Continental Europe                 | 8120-6802 |
| Denmark                            | 8120-6806 |
| Japan                              | 8120-6804 |
| Switzerland                        | 8120-6807 |
| United Kingdom/Hong Kong/Singapore | 8120-8709 |
| United States/Canada/Mexico        | 8120-6805 |

---

**Japan Power  
Cord Warning**

製品には、同梱された電源コードをお使い下さい。  
同梱された電源コードは、他の製品では使用出来ません。

**Please use the power cord supplied with your product. This power cord  
is not to be used with other products.**

---

---

# Installation Procedures

## Summary

1. **Prepare the installation site** ([page 2-5](#)). Ensure the physical environment is properly prepared, including having the correct network cabling ready to connect to the switch and having an appropriate location for the switch. *Please see [page 2-4](#) for some installation precautions.*
2. **Install a cl module** (optional—[page 2-7](#)).
3. **Install a transceiver** (optional—[page 2-8](#)). If you have installed a media flex cl module, you can now install one or two transceivers.
4. **Verify the switch passes self test** ([page 2-9](#)). Plug the switch into a power source and observe that the LEDs on the switch's front panel indicate correct switch operation. When self test is complete, unplug the switch.
5. **Mount the switch** ([page 2-11](#)). The Switch can be mounted in a 19-inch telco rack, in an equipment cabinet, or on a horizontal surface.
6. **Connect power to the switch** ([page 2-13](#)). Once the switch is mounted, plug it into the nearby main power source.
7. **Connect the network cables** ([page 2-14](#)). Using the appropriate network cables, connect the network devices to the switch ports.
8. **Connect a Redundant Power Supply (RPS),** (optional—[page 2-15](#)). You may wish to use the RPS option with your Switch. Connect the RPS using the cables supplied with the RPS, to the back of the switch.
9. **Connect a console to the switch** (optional—[page 2-18](#)). You may wish to modify the switch's configuration, for example, to configure an IP address so it can be managed using a web browser, from an SNMP network management station, or through a Telnet session. Configuration changes can be made easily by using the included console cable to connect a PC to the switch's console port.

At this point, the switch is fully installed. See the rest of this chapter if you need more detailed information on any of these installation steps.

## Installation Precautions:

Follow these precautions when installing the Switch 6400cl Series devices.

### WARNING

- **The rack or cabinet should be adequately secured to prevent it from becoming unstable and/or falling over. Devices installed in a rack or cabinet should be mounted as low as possible, with the heaviest devices at the bottom and progressively lighter devices installed above.**
- **For safe operation, do not install the switch with the back face of the switch (with the fan vents) facing either downward or upward.**
- **Left side vents cannot be placed downward. (That is, the left side of the unit while facing the front.)**
- **For safe operation, use only screws provided with your rack mount kit to secure mounting brackets to the switch. Use of longer or improper screws may damage internal components**

### Cautions

- Ensure the power source circuits are properly grounded, then use the power cord supplied with the switch to connect it to the power source.
- If your installation requires a different power cord than the one supplied with the switch, be sure to use a power cord displaying the mark of the safety agency that defines the regulations for power cords in your country. The mark is your assurance that the power cord can be used safely with the switch.
- When installing the switch, the AC outlet should be near the switch and should be easily accessible in case the switch must be powered off.
- Ensure the switch does not overload the power circuits, wiring, and over-current protection. To determine the possibility of overloading the supply circuits, add together the ampere ratings of all devices installed on the same circuit as the switch and compare the total with the rating limit for the circuit. The maximum ampere ratings are usually printed on the devices near the AC power connectors.
- Do not install the switch in an environment where the operating ambient temperature might exceed 55°C (131°F)<sup>1</sup>.
- Ensure the air flow around the sides and back of the switch is not restricted.
- For safe operation, proper switch cooling, and reduction of electromagnetic emissions, ensure a slot cover is installed on any unused module slot.

<sup>1</sup> If you are installing either of the Switch 6400cl Series switches using one of the fiber transceivers, the operating ambient temperature should not exceed 40°C (104°F). See transceiver specifications in the *HP ProCurve Switch cl Modules Installation Guide*.

## 1. Prepare the Installation Site

**Cabling Infrastructure** - Ensure the cabling infrastructure meets the necessary network specifications. The copper ports accept CX4 cable with Infiniband-style connectors or fiber cable using a CX4 optical media converter (OMC). The fiber ports accept single-mode fiber optic cable with SC connectors.

Table 2-1. Fiber-Optic Cables

| Port Type                                                                       | Cable Specifications                                                                                                                                                                                         | Connector Type | Supported Length                                                                                                                                                                                                                                                                                                                                       |
|---------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 10-GbE SR                                                                       | Multimode fiber-optic cable designed for Gigabit Ethernet: 62.5/125 μm (core/cladding) diameter or 50/125 μm, 850 nm, low metal content, complying with the ITU-T G.652 and ISO/IEC 793-2 Type B1 standards. | SC             | <ul style="list-style-type: none"><li>■ 62.5 μm cable:<ul style="list-style-type: none"><li>• 160 Mhz*km = 2-26 meters</li><li>• 200 Mhz*km = 2-33 meters</li></ul></li><li>■ 50 μm cable:<ul style="list-style-type: none"><li>• 400 Mhz*km = 2-66 meters</li><li>• 500 Mhz*km = 2-82 meters</li><li>• 2000 Mhz*km = 2-300 meters</li></ul></li></ul> |
| 10-GbE LR                                                                       | 9/125 μm (core/cladding) diameter, 1310 nm, low metal content, <b>single mode</b> fiber-optic cables, complying with the ITU-T G.652 and ISO/IEC 793-2 Type B1 standards.                                    | SC             | <b>single-mode cable:</b> 2-10 kilometers                                                                                                                                                                                                                                                                                                              |
| <b>Note:</b> Conditioning patch cord cables are not supported on 10-GbE speeds. |                                                                                                                                                                                                              |                |                                                                                                                                                                                                                                                                                                                                                        |

Table 2-2. Copper Cables

| Port Type                               | Cable Specifications                                                                                                                                                      | Connector Type          | Supported Length |
|-----------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------|------------------|
| CX4                                     | Speed 3.125Gbx4<br>(Cables compatible with the 802.1ak standard)                                                                                                          | CX4<br>Infiniband-style | 0.5-15 meters    |
| OMC CX4 Fiber (Optical Media Converter) | 12 fiber 50/125 μm (core/cladding) diameter, multimode Fiber ribbon cable. 12 fiber 62.5/125 μm (core/cladding) diameter, multimode Fiber ribbon cable is also supported. | MTP                     | 1-300 meters     |

- **Installation Location** - Before installing the switch, plan its location and orientation relative to other devices and equipment:
  - In the front of the switch, leave at least 7.6 cm (3 inches) of space for the twisted-pair and fiber-optic cabling.
  - In the back of the switch, leave at least 10.16 cm (4 inches) of space for the c1 module cabling.
  - On the sides of the switch, leave at least 7.6 cm (3 inches) for cooling, except if the switch is installed in an open EIA/TIA rack.

## 2. (Optional) Install or Remove a cl Module


---

### Caution

---

It is recommended the power to the switch be removed before inserting or extracting the expansion module. If the expansion module is inserted or removed with the switch powered on, a reset will occur. Only install or remove these modules during scheduled downtime.

1. Remove the cover plate




2. Insert the module aligning with the guides in the slot.
3. Once the contacts have engaged, use the extractor handles to seat the module completely.
4. Tighten the captive screws.

Refer to the *HP ProCurve Switch cl Modules Installation Guide* for more details.

If you have installed a media flex module, you can now install a transceiver. See the following step.


### 3. (Optional) Install or Remove a Transceiver

- a. Slide the transceiver in until it stops.<sup>1</sup>



<sup>1</sup> If you are installing either of the Switch 6400cl Series Switches using a fiber transceiver, the operating ambient temperature should not exceed 40°C (104°F). See transceiver specifications in the *HP ProCurve Switch cl Modules Installation Guide*.

- b. Push firmly until the gasket seats against the bulkhead.



---

#### Note

---

When switch power is on, the Link and Activity LEDs will come on for approximately two seconds and then go off. This is confirmation the transceiver is installed and seated correctly.

- c. If your transceiver has a bail, move the bail up, if not your transceiver is now completely installed.

Refer to the *HP ProCurve Switch cl Module Installation Guide* for more details.

To remove the transceiver:

If your transceiver has a bail, lower the bail until it is approximately horizontal, and then using the bail, pull the transceiver from the slot. If your transceiver does not have a bail, pull the transceiver straight out.

## 4. Verify the Switch Passes Self Test

Before mounting the switch in its network location, you should first verify it is working properly by plugging it into a power source and verifying it passes self test.

1. Connect the power cord supplied with the switch to the power connector on the back of the switch, and then into a properly grounded electrical outlet.



---

### Note


The Switch 6400cl Series devices do not have a power switch. They are powered on when the power cord is connected to the switch and to a power source. For safety, the power outlet should be located near the switch installation.

The switch automatically adjusts to any voltage between 100-240 volts and either 50 or 60 Hz. No voltage range settings are required.

If your installation requires a different power cord than the one supplied with the switch, be sure to use a power cord displaying the mark of the safety agency that defines the regulations for power cords in your country. The mark is your assurance that the power cord can be used safely with the switch.

---

2. Check the LEDs on the switch as described below.



When the switch is powered on, it performs a diagnostic self test. Self test takes approximately 50 seconds to complete.

## LED Behavior:

### During the self test:

- Initially, all the status and port LEDs are on for most of the duration of the test.
- Most of the LEDs go off and then may come on again during phases of the self test. For the duration of the self test, the Test LED stays on.

**When the self test completes successfully:**

- The **Power** and **Fan Status** LEDs remain on.
- The **Fault** and **Test LEDs** go off.
- The port LEDs (includes the expansion module LEDs) go into their normal operational mode:
  - If the ports are connected to active network devices, the LEDs behave according to their function, Link or Activity.
  - If the ports are not connected to active network devices, the LEDs will stay off.

If the LED display is different than what is described above, especially if the **Fault** and **Test LEDs** stay on for more than 60 seconds or they start blinking, the self test has not completed correctly. Refer to chapter 4, [“Troubleshooting”](#) for diagnostic help.

3. After the self test has completed successfully disconnect the power cord in preparation for mounting the switch.

## 5. Mount the Switch

After the switch passes self test, you are ready to mount the switch in a stable location. The Switch 6400cl Series devices can be mounted in these ways:

- in a rack or cabinet
- on a horizontal surface

### Rack or Cabinet Mounting

The Switch 6400cl Series devices are designed to be mounted in any EIA-standard 19-inch telco rack or communication equipment cabinet.

---

#### WARNING

---

**For safe operation, please read the installation precautions on [page 2-4](#), before mounting a switch.**

---

#### Equipment Cabinet Note

---

The 12-24 screws supplied with the switch are the correct threading for standard EIA/TIA open 19-inch racks. If you are installing the switch in an equipment cabinet such as a server cabinet, use the clips and screws that came with the cabinet in place of the 12-24 screws that are supplied with the switch.

Complete step 1, and plan which four holes you will be using in the cabinet and install all four clips. Then proceed to step 2.

## Rack Mounting the Switch 6400cl Series Devices

---

### WARNING

---

**For safe operation, use only screws provided with your rack mount kit to secure mounting brackets to the switch. Use of longer or improper screws may damage internal components**

1. Use a #1 Phillips (cross-head) screwdriver and attach the mounting brackets to the switch with the included 8-mm M4 screws.



---

### Note

---

The mounting brackets have multiple mounting holes and can be rotated allowing for a wide variety of mounting options. These include mounting the switch so its front face is flush with the face of the rack (as in the illustration above), or mounting it in a more balanced position.

2. Hold the switch with attached brackets up to the rack and move it vertically until rack holes line up with the bracket holes, then insert and tighten the four number 12-24 screws holding the brackets to the rack.



## Horizontal Surface Mounting

Place the switch on a table or other horizontal surface. The switch comes with rubber feet in the accessory kit that can be used to help keep the switch from sliding on the surface.

Attach the rubber feet to the four corners on the bottom of the switch within the embossed angled lines. Use a sturdy surface in an uncluttered area. You may want to secure the networking cables and switch power cord to the table leg or other part of the surface structure to help prevent tripping over the cords.

---

### Caution

---

Make sure the air flow is not restricted around the sides and back of the switch.

## 6. Connect the Switch to a Power Source

1. Plug the included power cord into the switch's power connector and into a nearby AC power source.
2. Re-check the LEDs during self test. See "LED Behavior" on [page 2-10](#)

## 7. Connect the Network Cables


Connect the network cables, described under “Cabling Infrastructure” (page 2-5), from the network devices or your patch panels to the fiber or copper ports on the switch.

### Connecting a fiber cable

**To connect:**

1. Remove the dust covers from the cable connectors and the port.
2. Aligning the notches on the cable connectors with the slots of the port, press the cable connector into the port until it snaps into place.

If the Link LED does *not* go on when the network cable is connected to the port, see “[Diagnosing with the LEDs](#)” on page 4-3, in chapter 4, “Troubleshooting”.



**To disconnect:**

Pull the cable connector straight out.

### Connecting a copper cable

**To connect:**

1. Push the copper cable connector into the copper port. Ensure the locking device locks the cable connector into place.

**To disconnect:**

Pull the cable connector straight out.

When a network cable from an active network device is connected to the port, the port LED for that port should go on. If the port LED does *not* go on when the network cable is connected to the port, see “[Diagnosing with the LEDs](#)” on page 4-3 in chapter 4, “Troubleshooting”.




## 8. (Optional) Connect a Redundant Power Supply to the Switch

The “HP ProCurve 600 Redundant and External Power Supply (hereafter referred to as the RPS/EPS)” (J8168A) is an accessory product for the Switch 6400cl Series devices and specific other HP ProCurve switches. The RPS/EPS provides redundant power to any one of up to six switch products, to back up the power supply in the switch in case of loss of AC power, or a fault condition. The RPS/EPS is an unmanaged power supply that only provides information by way of LEDs or through the port interfaces to attached devices.

### Operating Characteristics

The RPS/EPS has six connectors, each of which can provide redundant +12V power to a connected switch, but only one connector can provide this power at a given time. If a switch with no AC power is connected to an operating RPS/EPS, it will NOT immediately power up this new switch. Power can only be provided to a switch if it is first powered on and operating correctly. Then when the power to the switch fails, power will be provided from the RPS/EPS, if it is available, that is, if the RPS/EPS is not already providing power to a higher priority switch. If two or more devices fail, priority goes to the device plugged into the lower numbered port on the RPS/EPS unit. Consequently the most important switch must be plugged into port one on the RPS/EPS. In this state, the “Connected” LED should be ON, and the “Power Status” LED should be BLINKING. (Refer to the documentation that came with your RPS/EPS.)


Connect the RPS/EPS to the switch using one of the 6 supplied RPS cables.



LEDs

The RPS LEDs are located on the back of the RPS/EPS. These LEDs are duplicated on the front of the device. The following graphic shows an example of the back of the RPS/EPS. There are two green LEDs for each RPS port:


- Device Connected
- Power Status



The following states provide status of an RPS/EPS port.

| Fault     | Device Connected | Power Status | Message                                                |
|-----------|------------------|--------------|--------------------------------------------------------|
| Off       | Off              | Off          | Nothing Connected                                      |
| On or Off | Off              | On           | Not a valid state - should never happen                |
| Off       | On               | Off          | Switch is connected, RPS is available but not required |
| Off       | On               | On           | RPS is powering the connected device                   |
| Blinking  | Off              | Blinking     | RPS port is in fault mode                              |
| Off       | On               | Blinking     | Switch is requesting power, RPS can not provide it     |
| Blinking  | On               | Off          | Switch is unplugged, but RPS is powering switch        |

The following picture demonstrates an example of connectivity between an RPS/EPS device and a Switch device.



## RPS/EPS Operation

The RPS/EPS monitors the power signal from the switch by detecting that the RPS/EPS is connected to a switch with an RPS/EPS cable. When the power from the switch is no longer detected, the RPS/EPS will turn on and provide power to the switch within 1ms.

The RPS/EPS supports hot plugging of the RPS/EPS cable without causing a reboot of the switch or causing the power supply in either the RPS/EPS or switch to shut down temporarily or permanently. For more information refer to the documentation that came with the RPS/EPS.

## 9.(Optional) Connect a Console to the Switch

The switch has a full-featured, easy to use console interface for performing switch management tasks including the following:

- Monitor switch and port status and observe network activity statistics
- Modify the switch's configuration to optimize switch performance, enhance network traffic control, and improve network security
- Read the event log and access diagnostic tools to help in troubleshooting
- Download new software to the switch
- Add passwords to control access to the switch from the console, web browser interface, and network management stations

The console can be accessed through these methods:

- **Out-of-band:** The switch comes with a serial cable for connecting a PC or VT-100 terminal, to be used as a console, directly to the switch.
- **In-Band:** Access the console using Telnet from a PC or UNIX station on the network, and a VT-100 terminal emulator. This method requires that you first configure the switch with an IP address and subnet mask by using either out-of-band console access or through DHCP/Bootp. For more information on IP addressing and on starting a Telnet session, see chapter 3, [“Getting Started With Switch Configuration”](#), and the *Management and Configuration Guide*, which is on the Documentation CD-ROM that came with your switch.

The Switch can simultaneously support one out-of-band console session through the Console Port and one in-band Telnet console session.

### Terminal Configuration

To connect a console to the switch, configure the PC terminal emulator as a DEC VT-100 (ANSI) terminal or use a VT-100 terminal, and configure either one to operate with these settings:


- any baud rate from 1200 to 115200 (the switch senses the speed)
- 8 data bits, 1 stop bit, no parity, and flow control set to Xon/Xoff
- For the Windows Terminal program, also disable (uncheck) the “Use Function, Arrow, and Ctrl Keys for Windows” option
- For the Hilgraeve HyperTerminal program, select the “Terminal keys” option for the “Function, arrow, and ctrl keys act as” parameter.

If you want to operate the console using a different configuration, make sure you change the settings on both the terminal and on the switch so they are compatible. Change the switch settings first, save your changes, then change the terminal settings, then reboot the switch and reestablish the console session.

## Direct Console Access

To connect a console to the switch, follow these steps:

1. Connect the PC or terminal to the switch's Console Port using the console cable included with the Switch. (If your PC or terminal has a 25-pin serial connector, first attach a 9-pin to 25-pin straight-through adapter at one end of the console cable.)
2. Turn on the terminal or PC's power and, if using a PC, start the PC terminal program.
3. Press **[Enter]** two or three times and you will see the copyright page and the message "Press any key to continue". Press a key, and you will then see the switch console command (CLI) prompt, for example:




### HP ProCurve Switch 6400cl-6XG#

If you want to continue with console management of the switch at this time, see chapter 3, [“Getting Started With Switch Configuration”](#) for some basic configuration steps. For more detailed information, refer to the *Management and Configuration Guide*, which is on the Documentation CD-ROM that came with the switch.

## Sample Network Topologies


This section shows a few sample network topologies in which the Switch is implemented. For more topology information, see the HP network products World Wide Web site, <http://www.hp.com/go/procurve>.

### Three Tier Model



The Switch is designed to be used primarily in a wiring closet or in the data center as a distribution, high speed (10-GbE) switch to which edge switches supporting 10-GbE speeds (such as the HP ProCurve Switch 3400cl Series) would be connected using fiber or copper cables. The end nodes, printers and other peripherals, are then connected to the edge switch. The end node devices are connected to the edge switch by straight-through or crossover twisted-pair cables. Either cable type can be used because of the "IEEE Auto MDI/MDI-X" features on the Switch.

## Remote Campus



## Flexible Stacking

The Switch 6400cl Series devices can be connected together in two configurations depending on your need:


### High performance stack

This configuration provides:

- 228 gigabit ports
- 4.8 to 1 over-subscription


In this configuration each 3400cl switch is connected separately to its own port on the 6400cl providing 10-GbE connectivity to the 6400cl switch and the 6400cl switch is connected to the core using 10-GbE as well.

This topology also demonstrates an example of incorporating the use of a redundant power supply to support the 3400cl switches.



## Resiliency Using 6400cl Series as a meshed Cluster

The redundant topology increases the availability of a single switch by protecting against single points of failure. All hardware and paths are redundant and active (versus, Spanning Tree Blocking). If any hardware failure occurs, I/O communication can still be completed through another path.



— *This page is intentionally unused.* —

# Getting Started With Switch Configuration

---

This chapter is a guide for using the console Switch Setup screen to quickly assign an IP (Internet Protocol) address and subnet mask to the switch, set a Manager password, and, optionally, configure other basic features.

For more information on using the switch console and the other switch management interfaces: the web browser interface and the SNMP management tool, HP ProCurve Manager, please see the *Management and Configuration Guide*, which is on the Documentation CD-ROM that came with your switch.

## Recommended Minimal Configuration

In the factory default configuration, the switch has no IP (Internet Protocol) address and subnet mask, and no passwords. In this state, it can be managed only through a direct console connection. To manage the switch through in-band (networked) access, you should configure the switch with an IP address and subnet mask compatible with your network. Also, you should configure a Manager password to control access privileges from the console and web browser interface. Other parameters in the Switch Setup screen can be left at their default settings or you can configure them with values you enter.

Many other features can be configured through the switch's console interface, to optimize the switch's performance, to enhance your control of the network traffic, and to improve network security. Once an IP address has been configured on the switch, these features can be accessed more conveniently through a remote Telnet session, through the switch's web browser interface, and from an SNMP network management station running a network management program, such as HP ProCurve Manager. For a listing of switch features available with and without an IP address, refer to "How IP Addressing Affects Switch Operation" in the *Management and Configuration Guide*, which is on the Documentation CD-ROM that came with your switch.

For more information on IP addressing, refer to "IP Configuration" in the *Management and Configuration Guide*.

**Note**

By default, the switch is configured to acquire an IP address configuration from a DHCP or Bootp server. To use DHCP/Bootp instead of the manual method described in this chapter, see “DHCP/Bootp Operation” in the *Management and Configuration Guide*, which is on the Documentation CD-ROM that came with your switch.

## Using the Console Setup Screen

The quickest and easiest way to minimally configure the switch for management and password protection in your network is to use a direct console connection to the switch, start a console session, and access the Switch Setup screen.

1. Using the method described in the preceding section, connect a terminal device to the switch and display the switch console command (CLI) prompt (the default display).

The CLI prompt appears displaying the switch model number:

**HP Procurve Switch 6400cl-6XG#**

2. At the prompt, enter the **setup** command to display the Switch Setup screen. The following illustration shows the Setup screen with the default settings.

```

HP ProCurve Switch 6400cl-6XG                               1-Jan- 2004   2:59:24
=====  CONSOLE - MANAGER MODE  =====
                        Switch Setup

System Name : HP Procurve Switch / 6400cl-6XG
System Contact :
Manager Password :                               Confirm Password :
Logon Default : CLI                               Time Zone [0] : 0
Community Name : public                           Spanning Tree Enabled [No] : No

Default Gateway :
Time Sync Method [None] : TIMEP
TimeP Mode [Disabled] : Disabled

IP Config [DHCP/Bootp] : DHCP/Bootp
IP Address :
Subnet Mask :

Actions->  _Cancel    _Edit    _Save    _Help

Enter System Name - up to 25 characters.
Use arrow keys to change field selection, <Space> to toggle field choices,
and <Enter> to go to Actions.
  
```

3. Use the **[Tab]** key to select the **Manager Password** field and enter a manager password of up to 16 characters.

4. [Tab] to the **IP Config (DHCP/Bootp)** field and use the Space bar to select the **Manual** option.
5. [Tab] to the **IP Address** field and enter the IP address that is compatible with your network.
6. [Tab] to the **Subnet Mask** field and enter the subnet mask used for your network.
7. Press [Enter], then [S] (for **Save**).

Here is some information on the fields in the Setup screen. For more information on these fields, see the *Management and Configuration Guide*, which is on the Documentation CD-ROM that came with your switch:

| Parameter                                                                                                                                                                                                                                                                                             | Default         |                                                                                                                                     |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|-------------------------------------------------------------------------------------------------------------------------------------|
| System Name                                                                                                                                                                                                                                                                                           | blank           | Optional; up to 25 characters, including spaces                                                                                     |
| System Contact                                                                                                                                                                                                                                                                                        | blank           | Optional; up to 48 characters, including spaces                                                                                     |
| Manager Password                                                                                                                                                                                                                                                                                      | blank           | Recommended; up to 16 characters (no blank spaces)                                                                                  |
| Logon Default                                                                                                                                                                                                                                                                                         | CLI             | The default setting selects the command line interface for console access. The alternative is the menu interface.                   |
| Time Zone                                                                                                                                                                                                                                                                                             | 0 (none)        | Optional; 1440 to -1440. The number of minutes your location is to the West (-) or East (+) of GMT.                                 |
| Community Name                                                                                                                                                                                                                                                                                        | public          | Default setting recommended.                                                                                                        |
| Spanning Tree Enabled                                                                                                                                                                                                                                                                                 | No              | Default setting recommended unless STP is already running on your network or the switch will be used in complex network topologies. |
| Default Gateway                                                                                                                                                                                                                                                                                       | blank           | Optional; Enter the IP address of the next-hop gateway node if network traffic needs to be able to reach off-subnet destinations.   |
| Time Sync Method                                                                                                                                                                                                                                                                                      | None            | Optional; The protocol the switch uses to acquire a time signal. The options are SNTP and TimeP.                                    |
| TimeP Mode                                                                                                                                                                                                                                                                                            | Disabled        | Optional; The method the switch uses to acquire the TimeP server address.                                                           |
| IP Config (DHCP/Bootp)                                                                                                                                                                                                                                                                                | DHCP/Bootp      | Set to Manual unless a DHCP/Bootp server is used on your network to configure IP addressing.                                        |
| IP Address                                                                                                                                                                                                                                                                                            | xxx.xxx.xxx.xxx | Recommended; If you set IP Config to Manual, then enter an IP address compatible with your network.                                 |
| <p><b>Note:</b> The IP address and subnet mask assigned for the switch must be compatible with the IP addressing used in your network. For more information on IP addressing, see the <i>Management and Configuration Guide</i>, which is on the Documentation CD-ROM that came with your switch.</p> |                 |                                                                                                                                     |
| Subnet Mask                                                                                                                                                                                                                                                                                           | xxx.xxx.xxx.xxx | Recommended; If you entered an IP address, then enter a subnet mask compatible with your network.                                   |

## Where to Go From Here

The above procedure configures your switch with a Manager password, IP address, and subnet mask. As a result, with the proper network connections, you can now manage the switch from a PC equipped with Telnet, a web browser interface, or from an SNMP-based network management station using a tool such as HP ProCurve Manager.

Some basic information on managing your switch is included in the next section. For more information on the console, web browser, and SNMP management interfaces and all the features that can be configured on the Switch 6400, please see the *Management and Configuration Guide*, which is on the Documentation CD-ROM that came with your switch.

**To Recover from a Lost Manager Password:** If you cannot start a console session at the manager level because of a lost Manager password, you can clear all passwords and user names by getting physical access to the switch and pressing and holding the Clear button for a full second.

## Using the IP Address for Remote Switch Management

With your Switch 6400, you can use the switch's IP address to manage the switch from any PC that is on the same subnet as the switch. You can use either a Telnet session or a standard web browser to manage the switch.

### Starting a Telnet Session

To access the switch through a Telnet session, follow these steps:

1. Make sure the switch is configured with an IP address and that the switch is reachable from the PC that is running the Telnet session (for example, by using a Ping command to the switch's IP address).
2. Start the Telnet program on a PC that is on the same subnet as the switch and connect to the switch's IP address.
3. You will see the copyright page and the message "Press any key to continue". Press a key, and you will then see the switch console command (CLI) prompt, for example:

**HP Procurve Switch 6400cl#**

Enter **help** or **?** to see a list of commands that can be executed at the prompt. Entering any command followed by **help** provides more detailed context help information about the command. Entering any command followed by **?** displays a list of options that are available at that point in the command entry.

### Starting a Web Browser Session


Your Switch 6400 can be managed through a graphical interface that you can access from any PC or workstation on the network by running your web browser and typing in the switch's IP address as the URL. No additional software installation is required to make this interface available; it is included in the switch's onboard software.

**Getting Started With Switch Configuration**  
Using the IP Address for Remote Switch Management

The operating systems, web browsers, and Java support required to manage the switch through the browser interface are listed in the following table:

| Operating System    | Internet Explorer | Java Version          |
|---------------------|-------------------|-----------------------|
| Windows 2000 SP4    | 5.5 SP2, 6.0 SP1  | 1.3.1_12 and 1.4.2_05 |
| Windows XP SP1a     | 6.0 SP1           | 1.3.1_12 and 1.4.2_05 |
| Windows Server 2003 | 6.0 SP1           | 1.3.1_12 and 1.4.2_05 |

A typical web browser interface screen is shown in the next illustration.



For more information on using the web browser interface, please see the *Management and Configuration Guide*, which is on the Documentation CD-ROM that came with your switch.

An extensive help system is also available for the web browser interface. To access the help system though, the subnet on which the switch is installed must have access to the internet, or HP ProCurve Manager needs to be installed on a network management station that is on the subnet.

# Troubleshooting

---

This chapter describes how to troubleshoot your switch. This document describes troubleshooting mostly from a hardware perspective. You can perform more in-depth troubleshooting on the switch using the software tools available with the switch, including the full-featured console interface, the built-in web browser interface, and HP ProCurve Manager, the SNMP-based network management tool. For more information, see the chapter “Troubleshooting” in the *Management and Configuration Guide*, which is on the Documentation CD-ROM that came with your switch.

This chapter describes the following:

- basic troubleshooting tips ([page 4-1](#))
  - diagnosing with the LEDs ([page 4-3](#))
  - Proactive Networking tools ([page 4-6](#))
  - hardware diagnostic tests ([page 4-7](#))
  - restoring the factory default configuration ([page 4-9](#))
  - downloading new software to the Switch 6400 ([page 4-10](#))
  - HP Customer Support Services ([page 4-11](#))
- 

## Basic Troubleshooting Tips

Most problems are caused by the following situations. Check for these items first when starting your troubleshooting:

- **Faulty or loose cables.** Look for loose or obviously faulty connections. If they appear to be OK, make sure the connections are snug. If that does not correct the problem, try a different cable.
- **Non-standard cables.** Non-standard and miswired cables may cause network collisions and other network problems, and can seriously impair network performance. Use a new correctly-wired cable or compare your cable to the cable in appendix B, “Cables and Connectors” for pinouts and correct cable wiring.

- **Improper Network Topologies.** It is important to make sure you have a valid network topology. Common topology faults include excessive cable length and excessive repeater delays between end nodes. If you have network problems after recent changes to the network, change back to the previous topology. If you no longer experience the problems, the new topology is probably at fault. Sample topologies are shown at the end of chapter 2 in this book, and some topology configuration guidelines can be found online at the HP ProCurve web site, <http://www.hp.com/go/procurve>.

In addition, you should make sure that your network topology contains **no data path loops**. Between any two end nodes, there should be only one active cabling path at any time. Data path loops will cause broadcast storms that will severely impact your network performance.

For your switch, if you wish to build redundant paths between important nodes in your network to provide some fault tolerance, you should enable **Spanning Tree Protocol** support on the switch. This ensures only one of the redundant paths is active at any time, thus avoiding data path loops. Spanning Tree can be enabled through the switch console, the web browser interface, or HP ProCurve Manager.

The Switch 6400cl Series devices also support **Trunking**, which allows multiple network cables to be used for a single network connection without causing a data path loop. For more information on Spanning Tree and Trunking, see the *Management and Configuration Guide*, which is on the Documentation CD-ROM that came with your switch.

- **Check the port configuration.** A port on your switch may not be operating as you expect because it has been put into a “blocking” state by Spanning Tree, meshing, or LACP (automatic trunking). (Note that the normal operation of the Spanning Tree, meshing, and LACP features may put the port in a blocking state.) Or, the port just may have been configured as disabled through software.

Use the switch console to determine the port’s configuration and verify that there is not an improper or undesired configuration of any of the switch features that may be affecting the port. For more information, see the *Management and Configuration Guide*, which is on the Documentation CD-ROM that came with your switch.

For more information on possible network problems and their solutions, refer to the technical note “Troubleshooting LAN Performance and Intermittent Connectivity Problems”, which can be found on the HP ProCurve web site, <http://www.hp.com/go/procurve>, in the Information Library section.

## Diagnosing with the LEDs

Table 4-1 shows LED patterns on the switch and the switch modules that indicate problem conditions.

1. Check in the table for the LED pattern you see on your switch.
2. Refer to the corresponding diagnostic tip on the next few pages.

**Table 4-1. LED Error Indicators**

| LED Pattern Indicating Problems                                                                                                                                                                                                                                                                         |                       |                                                                              |            |                       |                       |                                       | Diagnostic Tips |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------|------------------------------------------------------------------------------|------------|-----------------------|-----------------------|---------------------------------------|-----------------|
| Power                                                                                                                                                                                                                                                                                                   | Fault                 | Module (Mdl) Status/Fault**                                                  | RPS Status | Test                  | Fan Status            | Port LED (Link)                       |                 |
| Off with power cord plugged in                                                                                                                                                                                                                                                                          | *                     | *                                                                            | *          | *                     | *                     | *                                     | ①               |
| On                                                                                                                                                                                                                                                                                                      | Prolonged On          | *                                                                            | *          | Prolonged On          | *                     | *                                     | ②               |
| On                                                                                                                                                                                                                                                                                                      | Blinking <sup>†</sup> | *                                                                            | *          | Blinking <sup>†</sup> | *                     | *                                     | ③               |
| On                                                                                                                                                                                                                                                                                                      | Blinking <sup>†</sup> | *                                                                            | *          | Off                   | Blinking <sup>†</sup> | *                                     | ④               |
| On                                                                                                                                                                                                                                                                                                      | Blinking <sup>†</sup> | See tip 5                                                                    | *          | Blinking <sup>†</sup> | *                     | Blinking <sup>†</sup>                 | ⑤               |
| On                                                                                                                                                                                                                                                                                                      | Off                   | *                                                                            | *          | Off                   | *                     | Off with cable connected              | ⑥               |
| On                                                                                                                                                                                                                                                                                                      | Off                   | *                                                                            | *          | Off                   | *                     | On, but the port is not communicating | ⑦               |
| On                                                                                                                                                                                                                                                                                                      | Blinking <sup>†</sup> | *                                                                            | On         | *                     | *                     | *                                     | ⑧               |
| On                                                                                                                                                                                                                                                                                                      | Blinking <sup>†</sup> | F <sup>1</sup> Blinking <sup>†</sup><br>B <sup>2</sup> Blinking <sup>†</sup> | *          | Blinking <sup>†</sup> | *                     | *                                     | ⑨               |
| <p>* This LED is not important for the diagnosis.</p> <p><sup>†</sup> The blinking behavior is an on/off cycle once every 1.6 seconds, approximately.</p> <p>** The Module Fault LED is located on the module in the rear of the switch.</p> <p><sup>1</sup> F - Front</p> <p><sup>2</sup> B - Back</p> |                       |                                                                              |            |                       |                       |                                       |                 |

## Diagnostic Tips:

| Tip | Problem                                                                                                                                                                            | Solution                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|-----|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ❶   | The switch is not plugged into an active AC power source, or the switch's power supply may have failed.                                                                            | <ol style="list-style-type: none"><li>1. Verify the power cord is plugged into an active power source and to the switch. Make sure these connections are snug.</li><li>2. Try power cycling the switch by unplugging and plugging the power cord back in.</li><li>3. If the Power LED is still not on, verify that the AC power source works by plugging another device into the outlet. Or try plugging the switch into a different outlet or try a different power cord.</li></ol> <p>If the power source and power cord are OK and this condition persists, the switch power supply may have failed. Call your HP-authorized LAN dealer, or use the electronic support services from HP to get assistance. See the Customer Support/Warranty booklet for more information.</p> |
| ❷   | A switch hardware failure has occurred. All the LEDs will stay on indefinitely.                                                                                                    | <p>Try power cycling the switch. If the fault indication reoccurs, the switch may have failed. Call your HP-authorized LAN dealer, or use the electronic support services from HP to get assistance. See the Customer Support/Warranty booklet for more information.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| ❸   | The switch has experienced a software failure during self test.                                                                                                                    | <ol style="list-style-type: none"><li>1. Try resetting the switch by pressing the Reset button on the front of the switch, or by power cycling the switch.</li><li>2. If the fault indication reoccurs, attach a console to the switch (as indicated in chapter 2) and configure it to operate at 9600 baud. Then, reset the switch. Messages should appear on the console screen and in the console log identifying the error condition. You can view the console log at that point by selecting it from the console Main Menu.</li></ol> <p>If necessary to resolve the problem, contact your HP-authorized LAN dealer, or use the electronic support services from HP to get assistance. See the Customer Support/Warranty booklet for more information.</p>                   |
| ❹   | One or more of the switch cooling fans may have failed.                                                                                                                            | <p>Try disconnecting power from the switch and wait a few moments. Then reconnect the power to the switch and check the LEDs again. If the error indication reoccurs, one or more of the fans has failed. The switch may continue to operate under this condition if the ambient temperature does not exceed normal room temperature, but for best operation, the switch should be replaced. Contact your HP-authorized LAN dealer, or use the electronic support services from HP to get assistance. See the Customer Support/Warranty booklet for more information.</p>                                                                                                                                                                                                         |
| ❺   | The network port for which the LED is blinking has experienced a self test or initialization failure.<br>If the Mdl Status LED is blinking, the affected port is on the cl Module. | <p>Try power cycling the switch. If the fault indication reoccurs, the switch port may have failed. Call your HP-authorized LAN dealer, or use the electronic support services from HP to get assistance. See the Customer Support/Warranty booklet for more information.</p> <p>If the port is a transceiver, verify it is one of the transceivers supported by the switch. Unsupported transceivers will be identified with this fault condition. The supported transceivers are listed in the <i>HP ProCurve Switch cl Modules Installation Guide</i>.</p> <p>To verify the port has failed, try removing and reinstalling the transceiver without having to power off the switch. If the port fault indication reoccurs, you will have to replace the transceiver.</p>        |

*continued on the next page*

| Tip | Problem                                                                                                                                               | Solution                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|-----|-------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ⑥   | The network connection is not working properly.                                                                                                       | <p>Try the following procedures:</p> <ul style="list-style-type: none"> <li>For the indicated port, verify both ends of the cabling, at the switch and the connected device, are connected properly.</li> <li>Verify the connected device and switch are both powered <i>on</i> and operating correctly.</li> <li>Verify you have used the correct cable type for the connection: <ul style="list-style-type: none"> <li>For fiber-optic connections, verify the transmit port on the switch is connected to the receive port on the connected device, and the switch receive port is connected to the transmit port on the connected device.</li> </ul> </li> <li>Verify the port has not been disabled through a switch configuration change. You can use the console interface, or, if you have configured an IP address on the switch, use the web browser interface, or HP ProCurve Manager network management software to determine the state of the port and re-enable the port if necessary.</li> <li>Verify the switch port configuration matches the configuration of the attached device. For example, if the switch port is configured as "Auto", the port on the attached device also <b>MUST</b> be configured as "Auto". Depending on the port type, twisted-pair or fiber-optic, if the configurations do not match, the results could be a very unreliable connection, or no link at all.</li> <li>If the other procedures do not resolve the problem, try using a different port or a different cable.</li> </ul> |
| ⑦   | The port may be improperly configured, or the port may be in a "blocking" state by the normal operation of the Spanning Tree, LACP, or IGMP features. | <p>Use the switch console to see if the port is part of a dynamic trunk (through the LACP feature) or to see if Spanning Tree is enabled on the switch, and to see if the port may have been put into a "blocking" state by those features. The <b>show lacp</b> command displays the port status for the LACP feature; the <b>show spanning-tree</b> command displays the port status for Spanning Tree.</p> <p>Also check the Port Status screen using the <b>show interfaces</b> command to see if the port has been configured as "disabled".</p> <p>Other switch features that may affect the port operation include VLANs and IGMP. Use the switch console to see how the port is configured for these features.</p> <p>For software troubleshooting tips, see the chapter "Troubleshooting" in the <i>Management and Configuration Guide</i>, which is on the Documentation CD-ROM that came with your switch.</p> <p>Make sure also, the device at the other end of the connection is indicating a good link to the switch. If it is not, the problem may be with the cabling between the devices or the connectors on the cable.</p>                                                                                                                                                                                                                                                                                                                                                                                       |
| ⑧   | An RPS is connected but the switch has experienced an internal power supply fault.                                                                    | Refer to the HP 600/610 External Power Supplies documentation. You may have to replace the switch.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| ⑨   | Expansion module is plugged in but has experienced a fault.                                                                                           | Check the rear of the switch. Check the module LEDs for indications. This condition will only occur during an initialization self test.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |

## Proactive Networking

The HP ProCurve Switch 6400cl Series devices have built-in management capabilities that proactively help you manage your network including:

- finding and helping you fix the most common network error conditions (for example, faulty network cabling, and non-standard network topologies)
- informing you of the problem with clear, easy-to-understand messages
- recommending network configuration changes to enhance the performance of your network

The following interfaces provide tests, indicators, and an event log that can be used to monitor the switch and its network connections and to help you take advantage of these proactive networking features:

- HP ProCurve Manager - an SNMP-based network management tool that is included with your switch.
- A graphical web browser interface that you can use to manage your switch from a PC running a supported web browser, for example Microsoft Internet Explorer.
- A full-featured easy-to-use console interface that you can access by connecting a standard terminal or PC running a terminal emulator to the switch's console port. The cable to make that connection is provided with your switch. The console interface is also accessible through a Telnet connection.

For more information on using these software tools to diagnose and manage your switch, see the “Troubleshooting” chapter in the *Management and Configuration Guide*, which is on the Documentation CD-ROM that came with your switch.

---

## Hardware Diagnostic Tests

### Testing the Switch by Resetting It

If you believe the switch is not operating correctly, you can reset the switch to test its circuitry and operating code. To reset a switch, either:

- unplug and plug in the power cord (power cycling)
- press the Reset button on the front of the switch

Power cycling the switch and pressing the Reset button both cause the switch to perform its power-on self test, which almost always will resolve any temporary operational problems. These reset processes also cause any network traffic counters to be reset to zero, and cause the System Up Time timer to reset to zero.

### Checking the Switch LEDs

The self test passes if the Fault and Test LEDs on the front of the switch go off after approximately 50 seconds. If these LEDs stay on longer than 60 seconds or begin blinking, there may be a problem with the switch.

See “Diagnosing With the LEDs” on [page 4-3](#) for information on interpreting the LED patterns and LED behaviors in chapter one.

### Checking Console Messages

Useful diagnostic messages may be displayed on the console screen when the switch is reset. As described in chapter 2 under step 7, “Connect a Console to the Switch”, connect a PC running a VT-100 terminal emulator program or a standard VT-100 terminal to the switch’s Console Port and configure it to run at 9600 baud, and with the other terminal communication settings shown on [page 2-18](#). Then, when you reset the switch, note the messages that are displayed. Additionally, you can check the switch event log, which can be accessed from the console using the **show log** command, or from the console Main Menu.

## Testing Switch-to-Device Network Communications

You can perform the following communication tests to verify the network is operating correctly between the switch and any connected device that can respond correctly to the communication test.

- **Link Test** – a physical layer test that sends IEEE 802.2 test packets to any device identified by its MAC address.
- **Ping Test** – a network layer test used on IP networks that sends test packets to any device identified by its IP address.

These tests can be performed through the switch console interface from a terminal connected to the switch or through a Telnet connection, or from the switch's web browser interface. For more information, see the *Management and Configuration Guide*, which is on the Documentation CD-ROM that came with your switch.

These tests can also be performed from an SNMP network management station running a program that can manage the switch, for example, HP ProCurve Manager.

## Testing End-to-End Network Communications

Both the switch and the cabling can be tested by running an end-to-end communications test – a test that sends known data from one network device to another through the switch. For example, if you have two PCs on the network that have LAN adapters between which you can run a link-level test or Ping test through the switch, you can use this test to verify that the entire communication path between the two PCs is functioning correctly. See your LAN adapter documentation for more information on running a link test or Ping test.

---

## Restoring the Factory Default Configuration

As part of your troubleshooting process on the switch, it may become necessary to return the switch to the factory default settings. This process momentarily interrupts the switch operation, clears any passwords, clears the console event log, resets the network counters to zero, performs a complete self test, and reboots the switch into its factory default configuration including deleting the IP address, if one is configured.

---

### Note

This process removes all switch configuration changes you have made from the factory default settings. This includes, for example, configuration of VLANs, Spanning Tree, trunks, and stacking. Returning the configuration of these features to their factory default settings (usually disabling them) may result in network connectivity issues.

If the switch has a valid configuration, and you are restoring the factory default settings for a reason other than configuration problems, you should save the switch configuration prior to performing the factory default reset. Then, after the reset and resolution of the original problem, you can restore the saved configuration to the switch. For both the save and restore processes, you can use the console **copy** command. For more information on this command, see the *Management and Configuration Guide*, which is on the Documentation CD-ROM that came with your switch.

---

You can restore the factory default configuration either on the switch itself, or through the switch console.

To execute the factory default reset on the switch, perform these steps:

1. Using pointed objects, simultaneously press both the Reset and Clear buttons on the front of the switch.
2. Continue to press the Clear button while releasing the Reset button.
3. When the Test LED begins to blink, release the Clear button.

The switch will then complete its self test and begin operating with its configuration restored to the factory default settings.

To restore the factory default configuration using the console, execute the **erase startup-config** command from the console command prompt.

## Downloading New Switch Software

When product enhancements occur for the switch, new software can be downloaded to the switch through several methods, for product enhancements and new features. For more information, see the *Management and Configuration Guide*, which is on the Documentation CD-ROM that came with your switch.

The new switch software would be available on the HP ProCurve web site, <http://www.hp.com/go/procurve>.

# HP Customer Support Services

If you are still having trouble with your switch, Hewlett-Packard offers support 24 hours a day, seven days a week through the use of a number of automated electronic services. See the Customer Support/Warranty booklet that came with your switch for information on how to use these services to get technical support. The HP ProCurve web site, <http://www.hp.com/go/procurve> also provides up-to-date support information.

Additionally, your HP-authorized network reseller can provide you with assistance, both with services that they offer and with services offered by HP.

## Before Calling Support

Before calling your networking dealer or HP Support, to make the support process most efficient, you first should have retrieved the following information:

| Information Item                                                                                                                                                                                                                                    | Information Location                                      |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------|
| <ul style="list-style-type: none"><li>product identification</li></ul>                                                                                                                                                                              | the front of the switch, Switch 6400cl (J8433A or J8474A) |
| <ul style="list-style-type: none"><li>details about the switch's status including the software (OS) version, a copy of the switch configuration, a copy of the switch Event Log, and a copy of the switch status and counters information</li></ul> | switch console: <b>show tech</b> command                  |
| <ul style="list-style-type: none"><li>copy of your network topology map, including network addresses assigned to the relevant devices</li></ul>                                                                                                     | your network records                                      |

— *This page is intentionally unused.* —

# Specifications

---

## Physical

|                        |                     |
|------------------------|---------------------|
| <b>Width:</b>          | 44.3 cm (17.4 in)   |
| <b>Depth:</b>          | 43.0 cm (16.9 in)   |
| <b>Height:</b>         | 4.4 cm (1.7 in)     |
| <b>Weight:</b>         |                     |
| <b>6400cl (J8433A)</b> | 5.6 kg (12.35 lbs)  |
| <b>6410cl (J8474A)</b> | 6.15 kg (13.56 lbs) |

## Electrical

The switch automatically adjusts to any voltage between 100-240 volts and either 50 or 60 Hz.

|                         |               |
|-------------------------|---------------|
| <b>AC voltage:</b>      | 100-240 volts |
| <b>Maximum current:</b> | 3.0A/1.5A     |
| <b>Frequency range:</b> | 50/60 Hz      |

## Environmental

|                                                | Operating                                | Non-Operating                  |
|------------------------------------------------|------------------------------------------|--------------------------------|
| <b>Temperature:</b>                            | 0°C to 55°C (32°F to 131°F) <sup>1</sup> | -40°C to 70°C (-40°F to 158°F) |
| <b>Relative humidity:<br/>(non-condensing)</b> | 15% to 95% at 40°C (104°F)               | 15% to 90% at 65°C (149°F)     |
| <b>Maximum altitude:</b>                       | 4.6 Km (15,000 ft)                       | 4.6 Km (15,000 ft)             |

<sup>1</sup> If you are installing either of the Switch 6400cl Series switches using one of the fiber transceivers, the operating ambient temperature should not exceed 40°C (104°F). See transceiver specifications in the *HP ProCurve Switch cl Modules Installation Guide*.

## Acoustic

Geraeuschemission LwA=55 dB am fiktiven Arbeitsplatz nach DIN 45635 T.19

Noise Emission LwA=55 dB at virtual workspace according to DIN 45635 T.19

## Connectors

- The copper ports are compatible with the IEEE 802.1ak standards.
- The fiber-optic ports are compatible with the IEEE 802.1ae standards.
- The console port is a standard RS-232, (standard DB-9) connector.

## Safety

Complies with:

- EN60950 / IEC60950
- CSA 22.2 No. 60950
- UL 60950

## Lasers

The following products are Class 1 Laser Products.

Laser Klasse 1:

- The 10-GbE X2 LR-SC transceiver

The following products are Class 1m Laser Products.

Laser Klasse 1m:

- The 10-GbE X2 SR-SC transceiver

The transceivers comply with IEC 60825.

# Safety and EMC Regulatory Statements

## Safety Information



Documentation reference symbol. If the product is marked with this symbol, refer to the product documentation to get more information about the product.

### **WARNING**

A **WARNING** in the manual denotes a hazard that can cause injury or death.

### Caution

A Caution in the manual denotes a hazard that can damage equipment.

Do not proceed beyond a **WARNING** or Caution notice until you have understood the hazardous conditions and have taken appropriate steps.

### **Grounding**

These are safety class I products and have protective earthing terminals. There must be an uninterruptible safety earth ground from the main power source to the product's input wiring terminals, power cord, or supplied power cord set. Whenever it is likely that the protection has been impaired, disconnect the power cord until the ground has been restored.

For LAN cable grounding:

- If your LAN covers an area served by more than one power distribution system, be sure their safety grounds are securely interconnected.
- LAN cables may occasionally be subject to hazardous transient voltages (such as lightning or disturbances in the electrical utilities power grid). Handle exposed metal components of the network with caution.

### **Servicing**

There are no user-serviceable parts inside these products. Any servicing, adjustment, maintenance, or repair must be performed only by service-trained personnel.

These products do not have a power switch; they are powered on when the power cord is plugged in.

## Informations concernant la sécurité



Symbole de référence à la documentation. Si le produit est marqué de ce symbole, reportez-vous à la documentation du produit afin d'obtenir des informations plus détaillées.

### **WARNING**

Dans la documentation, un **WARNING** indique un danger susceptible d'entraîner des dommages corporels ou la mort.

### Caution

Un texte de mise en garde intitulé Caution indique un danger susceptible de causer des dommages à l'équipement.

Ne continuez pas au-delà d'une rubrique **WARNING** ou Caution avant d'avoir bien compris les conditions présentant un danger et pris les mesures appropriées.

Cet appareil est un produit de classe I et possède une borne de mise à la terre. La source d'alimentation principale doit être munie d'une prise de terre de sécurité installée aux bornes du câblage d'entrée, sur le cordon d'alimentation ou le cordon de raccordement fourni avec le produit. Lorsque cette protection semble avoir été endommagée, débrancher le cordon d'alimentation jusqu'à ce que la mise à la terre ait été réparée.

Mise à la terre du câble de réseau local:

- si votre réseau local s'étend sur une zone desservie par plus d'un système de distribution de puissance, assurez-vous que les prises de terre de sécurité soient convenablement interconnectées.
- Les câbles de réseaux locaux peuvent occasionnellement être soumis à des surtensions transitoires dangereuses (telles que la foudre ou des perturbations dans le réseau d'alimentation public). Manipulez les composants métalliques du réseau avec précautions.

Aucune pièce contenue à l'intérieur de ce produit ne peut être réparée par l'utilisateur. Tout dépannage, réglage, entretien ou réparation devra être confié exclusivement à un personnel qualifié.

Cet appareil ne comporte pas de commutateur principal ; la mise sous tension est effectuée par branchement du cordon d'alimentation.

---

## Hinweise zur Sicherheit



Symbol für Dokumentationsverweis. Wenn das Produkt mit diesem Symbol markiert ist, schlagen Sie bitte in der Produktdokumentation nach, um mehr Informationen über das Produkt zu erhalten.

### **WARNING**

Eine **WARNING** in der Dokumentation symbolisiert eine Gefahr, die Verletzungen oder sogar Todesfälle verursachen kann.

### Caution

Caution in der Dokumentation symbolisiert eine Gefahr, die das Gerät beschädigen kann.

Fahren Sie nach dem Hinweis **WARNING** oder Caution erst fort, nachdem Sie den Gefahrenzustand verstanden und die entsprechenden Maßnahmen ergriffen haben.

Dies ist ein Gerät der Sicherheitsklasse I und verfügt über einen schützenden Erdungsterminal. Der Betrieb des Geräts erfordert eine ununterbrochene Sicherheitserdung von der Hauptstromquelle zu den Geräteingabeterminals, den Netzkabeln oder dem mit Strom belieferten Netzkabelsatz voraus. Sobald Grund zur Annahme besteht, daß der Schutz beeinträchtigt worden ist, das Netzkabel aus der Wandsteckdose herausziehen, bis die Erdung wiederhergestellt ist.

Für LAN-Kabelerdung:

- Wenn Ihr LAN ein Gebiet umfaßt, das von mehr als einem Stromverteilungssystem beliefert wird, müssen Sie sich vergewissern, daß die Sicherheitserdungen fest untereinander verbunden sind.
- LAN-Kabel können gelegentlich gefährlichen Übergangsspannungen ausgesetzt werden (beispielsweise durch Blitz oder Störungen in dem Starkstromnetz des Elektrizitätswerks). Bei der Handhabung exponierter Metallbestandteile des Netzwerkes Vorsicht walten lassen.

Dieses Gerät enthält innen keine durch den Benutzer zu wartenden Teile. Wartungs-, Anpassungs-, Instandhaltungs- oder Reparaturarbeiten dürfen nur von geschultem Bedienungspersonal durchgeführt werden.

Dieses Gerät hat keinen Netzschalter; es wird beim Anschließen des Netzkabels eingeschaltet.

## Considerazioni sulla sicurezza



### **WARNING**

Simbolo di riferimento alla documentazione. Se il prodotto è contrassegnato da questo simbolo, fare riferimento alla documentazione sul prodotto per ulteriori informazioni su di esso.

### Caution

La dicitura **WARNING** denota un pericolo che può causare lesioni o morte.

La dicitura **Caution** denota un pericolo che può danneggiare le attrezzature.

Non procedere oltre un avviso di **WARNING** o di **Caution** prima di aver compreso le condizioni di rischio e aver provveduto alle misure del caso.

Questo prodotto è omologato nella classe di sicurezza I ed ha un terminale protettivo di collegamento a terra. Dev'essere installato un collegamento a terra di sicurezza, non interrompibile che vada dalla fonte d'alimentazione principale ai terminali d'entrata, al cavo d'alimentazione oppure al set cavo d'alimentazione fornito con il prodotto. Ogniqualvolta vi sia probabilità di danneggiamento della protezione, disinserite il cavo d'alimentazione fino a quando il collegamento a terra non sia stato ripristinato.

Per la messa a terra dei cavi LAN:

- se la vostra LAN copre un'area servita da più di un sistema di distribuzione elettrica, accertatevi che i collegamenti a terra di sicurezza siano ben collegati fra loro;
- i cavi LAN possono occasionalmente andare soggetti a pericolose tensioni transitorie (ad esempio, provocate da lampi o disturbi nella griglia d'alimentazione della società elettrica); siate cauti nel toccare parti esposte in metallo della rete.

Nessun componente di questo prodotto può essere riparato dall'utente. Qualsiasi lavoro di riparazione, messa a punto, manutenzione o assistenza va effettuato esclusivamente da personale specializzato.

Questo apparato non possiede un commutatore principale; si mette scotto tensione all'inserirsi il cavo d'alimentazione.

## Consideraciones sobre seguridad



### WARNING

Símbolo de referencia a la documentación. Si el producto va marcado con este símbolo, consultar la documentación del producto a fin de obtener mayor información sobre el producto.

### Caution

Una **WARNING** en la documentación señala un riesgo que podría resultar en lesiones o la muerte.

Una Caution en la documentación señala un riesgo que podría resultar en averías al equipo.

No proseguir después de un símbolo de **WARNING** o Caution hasta no haber entendido las condiciones peligrosas y haber tomado las medidas apropiadas.

Este aparato se enmarca dentro de la clase I de seguridad y se encuentra protegido por una borna de puesta a tierra. Es preciso que exista una puesta a tierra continua desde la toma de alimentación eléctrica hasta las bornas de los cables de entrada del aparato, el cable de alimentación o el juego de cable de alimentación suministrado. Si existe la probabilidad de que la protección a tierra haya sufrido desperfectos, desenchufar el cable de alimentación hasta haberse subsanado el problema.

Puesta a tierra del cable de la red local (LAN):

- Si la LAN abarca un área cuyo suministro eléctrico proviene de más de una red de distribución de electricidad, cerciorarse de que las puestas a tierra estén conectadas entre sí de modo seguro.
- Es posible que los cables de la LAN se vean sometidos de vez en cuando a voltajes momentáneos que entrañen peligro (rayos o alteraciones en la red de energía eléctrica). Manejar con precaución los componentes de metal de la LAN que estén al descubierto.

Este aparato no contiene pieza alguna susceptible de reparación por parte del usuario. Todas las reparaciones, ajustes o servicio de mantenimiento debe realizarlos solamente el técnico.

Este producto no tiene interruptor de potencia; se activa cuando se enchufa el cable de alimentación.

## Safety Information (Japan)

安全性の考慮

安全記号



マニュアル参照記号。製品にこの記号がついている場合はマニュアルを参照し、注意事項等をご確認ください。

**WARNING** マニュアル中の「WARNING」は人身事故の原因となる危険を示します。

**CAUTION** マニュアル中の「CAUTION」は装置破損の原因となる危険を示します。

「WARNING」や「CAUTION」の項は飛ばさないで必ずお読みください。危険性に関する記載事項をよく読み、正しい手順に従った上で次の事項に進んでください。

これは安全性クラス I の製品で保護用接地端子を備えています。主電源から製品の入力配線端子、電源コード、または添付の電源コード・セットまでの間、切れ目のない安全接地が存在することが必要です。もしこの保護回路が損なわれたことが推測されるときは、接地が修復されるまで電源コードを外しておいてください。

LAN ケーブルの接地に関して:

- もし貴社の LAN が複数の配電システムにより電力を受けている領域をカバーしている場合には、それらのシステムの安全接地が確実に相互に結合されていることを確認してください。
- LAN ケーブルは時として危険な過度電圧（例えば雷や、配電設備の電力網での障害）にさらされることがあります。露出した金属部分の取扱いには十分な注意をはらってください。

本製品の内部にはユーザーが修理できる部品はありません。サービス、調整、保守および修理はサービス訓練を受けた専門家におまかせください。

本製品には電源スイッチがありません。電源コードを接続したとき電源入となります。

### Japan Power Cord Warning

製品には、同梱された電源コードをお使い下さい。  
同梱された電源コードは、他の製品では使用出来ません。

## Safety Information (China)

### HP 网络产品使用安全手册

#### 使用须知

欢迎使用惠普网络产品，为了您及仪器的安全，请您务必注意如下事项：

1. 仪器要和地线相接，要使用有正确接地插头的电源线，使用中国国家规定的220V电源。
2. 避免高温和尘土多的地方，否则易引起仪器内部部件的损坏。
3. 避免接近高温，避免接近直接热源，如直射太阳光、暖气等其它发热体。
4. 不要有异物或液体落入机内，以免部件短路。
5. 不要将磁体放置于仪器附近。

#### 警告

为防止火灾或触电事故，请不要将该机放置于淋雨或潮湿处。

#### 安装

安装辅助管理模块，请参看安装指南。

#### 保修及技术支持

如果您按照以上步骤操作时遇到了困难，或想了解其它产品性能，请按以下方式与我们联系。

如是硬件故障：

1. 与售出单位或当地维修机构联系。
2. 中国惠普有限公司维修中心地址：  
北京市海淀区知春路49号希格玛大厦  
联系电话：010-62623888 转 6101  
邮政编码：100080

如是软件问题：

1. 惠普用户响应中心热线电话：010-65645959
2. 传真自动回复系统：010-65645735

---

## EMC Regulatory Statements

### U.S.A.

#### FCC Class A

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause interference to radio communications. Operation of this equipment in a residential area may cause interference in which case the user will be required to correct the interference at his own expense.

### Canada

This product complies with Class A Canadian EMC requirements.

### Australia/New Zealand



This product complies with Australia/New Zealand EMC Class A requirements.

### Japan

#### VCCI Class A

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラスA情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

## Korea

사용자 안내문 : A 급기기

이기는 업무용으로 전자파 적합등록을 받은 기기 이오니, 판매자 또는 사용자는 이점을 주의하시기 바라며, 만약 잘못 구입하셨을 때에는 구입한 곳에서 비업무용으로 교환하시기 바랍니다.

## Taiwan

警告使用者：這是甲類的資訊產品，在居住的環境中使用時，可能會造成射頻干擾，在這種情況下，使用者會被要求採取某些適當的對策。

## European Community



### DECLARATION OF CONFORMITY

according to ISO/IEC Guide 22 and EN 45014

**Manufacturer's Name:** Hewlett-Packard Company

**Manufacturer's Address:** 8000 Foothills Blvd.  
Roseville, CA 95747-5502  
U.S.A.

**declares, that the product**

**Product Name:** HP ProCurve Switch 10-GbE CX4 6400cl-6XG  
HP ProCurve Switch 10-GbE X2 6410cl-6XG

**Product Number(s):** J8433A, J8474A

**Regulatory Model:** RSVLC-0409

**Product Options:** All

**conforms to the following Product Specifications:**

Safety: EN 60950:2000 / IEC 60950:1999

EMC: EN 55022:1998 / CISPR 22:1997 Class A  
EN 55024:1998 +A1 / CISPR 24:1997 +A1  
EN 61000-3-2:2000 / IEC 61000-3-2:2001  
EN 61000-3-3:1995 +A1 / IEC 61000-3-3:1994 +A1

**Supplementary Information:**

The product herewith complies with the requirements of the Low Voltage Directive 73/23/EEC and the EMC Directive 89/336/EEC and carries the CE marking accordingly.

This product is assigned a Regulatory Model Number which stays with the regulatory aspects of the design. The Regulatory Model Number is the main product identifier in the regulatory documentation and test reports. This number should not be confused with the product marketing name or product numbers.

Roseville, 5 January 2005

  
Mike Avery, Regulatory Engineering Mgr.

European Contact: Your local Hewlett-Packard Sales and Service Office or Hewlett-Packard GmbH, Department HQ-TRE, Herrenberger Straße 140, D-71034 Böblingen (FAX: + 49-7031-14-3143)

# Index

---

## Numerics

- 10 Gigabit
  - 10-GbE ... 1-1, 1-4, 1-10

## A

- AC power connector
  - location on back of switch ... 1-9
- Act LED ... 1-5, 1-7–1-8

## B

- back of switch
  - cl module slot ... 1-9
  - description ... 1-9
  - power connector ... 1-9
  - RPS input port ... 1-9
- basic switch configuration
  - IP address ... 3-3
  - manager password ... 3-2
  - subnet mask ... 3-3
  - Switch Setup screen ... 3-2
- basic troubleshooting tips ... 4-1
- blinking LEDs
  - error indications ... 4-3
- Bootp
  - automatic switch configuration ... 3-2
  - for in-band access ... 2-18
- buttons
  - Clear button ... 1-4
  - Reset button ... 1-4

## C

- cabinet
  - mounting the switch in ... 2-11
- cables
  - connecting cables to switch ports ... 2-14
  - effects of non-standard cables ... 4-1
  - infrastructure requirements ... 2-5
  - serial, for direct console connection ... 2-19
- cabling infrastructure ... 2-5

- cl module
  - install or remove ... 2-7
- cl module slot ... 1-9
- Clear button
  - deleting passwords ... 1-4
  - description ... 1-4
  - location on switch ... 1-3–1-4
  - restoring factory default configuration ... 1-5, 4-9
  - to delete password protection ... 3-4
- CLI prompt, console
  - displaying ... 2-19
- configuration
  - checking when troubleshooting ... 4-2
  - DHCP/Bootp ... 3-2
  - IP address ... 3-3
  - IP address, manually ... 3-2
  - manager password ... 3-2
  - restoring factory defaults ... 1-5, 4-9
  - subnet mask ... 3-3
  - Switch Setup screen ... 3-2
- connecting the switch to a power source ... 2-13
- connecting the switch to an RPS/EPS ... 2-17
- connector specifications ... A-2
- console
  - checking messages during
    - troubleshooting ... 4-7
  - displaying the CLI prompt ... 2-19
  - features ... 2-18
  - how to connect in-band ... 2-18
  - how to connect out-of-band ... 2-18
  - serial cable connection ... 2-19
  - Switch Setup screen ... 3-2
  - Telnet access ... 3-5
  - terminal configuration ... 2-18
- console port ... 1-4
  - location on switch ... 1-3

## D

- deleting passwords ... 1-4

- description
  - back of switch ... 1-9
  - front of switch ... 1-3
  - LEDs ... 1-5
  - switch ... 1-1
- DHCP
  - automatic switch configuration ... 3-2
  - for in-band access ... 2-18
- diagnostic tests ... 4-7
  - checking the console messages ... 4-7
  - checking the LEDs ... 4-7
  - end-to-end connectivity ... 4-8
  - testing the switch only ... 4-7
- downloading new switch software ... 4-10

## E

- electrical specifications, switch ... A-1
- EMC regulatory statements ... B-8
- environmental specifications, switch ... A-1
- expansion modules LEDs ... 1-8

## F

- factory default configuration, restoring ... 1-5, 4-9
- Fan Status LED ... 1-6
- Fault LED ... 1-5
  - behavior during self test ... 2-11
  - behaviors ... 1-5
  - blinking definition ... 1-6
  - showing error conditions ... 4-3
- features
  - console ... 2-18
  - switch ... 1-10
- front of switch ... 1-3
  - Clear button ... 1-4
  - LEDs ... 1-5
  - network ports ... 1-4
  - Reset button ... 1-4

## H

- horizontal surface
  - mounting switch on ... 2-13

## I

- in-band ... 3-1
- in-band console access
  - types of ... 2-18
- included parts ... 2-1
- installation
  - cl module ... 2-7
  - connecting the switch to a power source ... 2-13
  - horizontal surface mounting ... 2-13
  - location considerations ... 2-6
  - network cable requirements ... 2-5
  - precautions ... 2-4
  - rack or cabinet mounting ... 2-11
  - site preparation ... 2-5
  - summary of steps ... 2-3
  - transceiver ... 2-8
- IP address
  - configuring ... 3-3

## L

- LEDs
  - Act ... 1-5, 1-7–1-8
  - behavior during self test ... 2-10
  - blinking definition ... 1-6
  - checking during troubleshooting ... 4-7
  - descriptions of ... 1-5
  - EPS/RPS ... 2-16
  - error indications ... 4-3
  - expansion module ... 1-8
  - Fan Status ... 1-6
  - Fault ... 1-5
    - behavior during self test ... 2-11

- showing error conditions ... 4-3
- Link ... 1-5, 1-7–1-8
- location on switch ... 1-3
- on switch ... 1-5
- port
  - description ... 1-5
- Port LED View select indicators ... 1-5
- Port View
  - selecting the display ... 1-7
- Power ... 1-5
  - behavior during self test ... 2-11
- Self Test ... 1-6
  - behavior during self test ... 2-10
- Link LED ... 1-7
- Link LEDs ... 1-5, 1-8
- link test ... 4-8
- location for the switch, considerations ... 2-6

## M

- mounting the switch
  - in a rack or cabinet ... 2-11
  - precautions ... 2-4
  - on a horizontal surface ... 2-13

## N

- network cables
  - required types ... 2-5
- network devices
  - connecting to the switch ... 2-14
- network ports
  - connecting to ... 2-14
  - location on switch ... 1-4
  - standards compliance ... A-2
  - types of ... 1-4
- non-standard network cables, effects ... 4-1

## O

- out-of-band console access ... 3-5

## P

- parts, included with the switch ... 2-1
- password
  - configuring ... 3-2
- passwords
  - deleting with the Clear button ... 3-4
  - if you lose the password ... 3-4
- passwords, deleting ... 1-4
- physical specifications, switch ... A-1
- Ping test ... 4-8
- port configuration
  - checking when troubleshooting ... 4-2
- Port LED View
  - indicator LEDs ... 1-7
  - select button ... 1-7
  - selecting the display ... 1-7
- port LEDs
  - description ... 1-5
  - Link ... 1-5, 1-8
  - normal operation ... 2-11
- ports
  - connecting to ... 2-14
  - console ... 2-18
  - network connections ... 2-14
- power connector ... 1-9
- Power LED ... 1-5
  - behavior during self test ... 2-11
  - behaviors ... 1-5
- power source
  - connecting the switch to ... 2-13
- precautions
  - mounting the switch ... 2-4
  - power requirements ... 2-4
- preparing the installation site ... 2-5
- Proactive Network tools
  - diagnostics with ... 4-6

## R

- rack
  - mounting precautions ... 2-4
  - mounting the switch in ... 2-11
- Redundant Power Supply ... 2-15

- redundant power supply
  - RPS/EPS ... 1-1
- regulatory statements ... B-8
- remote campus
  - topology with ... 2-21
- Reset button
  - description ... 1-4
  - location on switch ... 1-3–1-4
  - restoring factory default configuration ... 4-9
- resetting the switch
  - factory default reset ... 4-9
  - location of Reset button ... 1-4
  - troubleshooting procedure ... 4-7
- RPS input port ... 1-9
- RPS LED behavior ... 1-6
- RPS/EPS ... 2-15
  - cables ... 2-15
  - connecting to a switch ... 2-17
  - operation ... 2-17

## S

- safety and regulatory statements ... B-1
- safety specifications ... A-2
- selecting the Port LED View display ... 1-7
- self test
  - Fault LED behavior ... 2-11
  - LED behavior during ... 2-10
  - Power LED behavior ... 2-11
- Self Test LED ... 1-6
  - behavior during factory default reset ... 4-9
- serial cable
  - for direct console connection ... 2-19
- specifications
  - connectors ... A-2
  - electrical ... A-1
  - environmental ... A-1
  - physical ... A-1
  - safety ... A-2
- subnet mask
  - configuring ... 3-3
- summary
  - of switch installation ... 2-3

- switch
  - connecting to a power source ... 2-13
  - description ... 1-1
  - downloading new software ... 4-10
  - electrical specifications ... A-1
  - environmental specifications ... A-1
  - features ... 1-10
  - front panel description ... 1-3
  - included parts ... 2-1
  - LED descriptions ... 1-5
  - mounting in a rack or cabinet ... 2-11
  - mounting on horizontal surface ... 2-13
  - physical specifications ... A-1
- switch operation
  - verifying after installation ... 2-9
- Switch Setup screen ... 3-2
  - configuring a subnet mask ... 3-3
  - configuring an IP address ... 3-3
  - field descriptions ... 3-3

## T

- Telnet access to the console ... 3-5
- terminal configuration ... 2-18
- Test LED
  - behavior during self test ... 2-10
- testing
  - checking the console messages ... 4-7
  - checking the LEDs ... 4-7
  - diagnostic tests ... 4-7
  - end-to-end communications ... 4-8
  - link test ... 4-8
  - Ping test ... 4-8
  - switch operation ... 4-7
  - switch-to-device communications ... 4-8
- three tier model
  - sample topology ... 2-20
- tips for troubleshooting ... 4-1
- topologies
  - effects of improper topology ... 4-2
  - samples of ... 2-20
- transceiver
  - install or remove ... 2-8

- troubleshooting ... 4-1
  - basic tips ... 4-1
  - checking port configuration ... 4-2
  - checking the console messages ... 4-7
  - checking the LEDs ... 4-7
  - common network problems ... 4-1
  - diagnostic tests ... 4-7
  - effects of improper topology ... 4-2
  - effects of non-standard cables ... 4-1
  - link test ... 4-8
  - Ping test ... 4-8
  - Proactive Network tools ... 4-6
  - restoring factory default configuration ... 4-9
  - testing connections to other devices ... 4-8
  - testing end-to-end communications ... 4-8
  - testing the switch ... 4-7

## V

- VT-100 terminal
  - serial cable connection for ... 2-19

— *This page is intentionally unused.* —





Technical information in this document  
is subject to change without notice.

©Copyright 2001, 2005  
Hewlett-Packard Development Company, L.P.  
Reproduction, adaptation, or translation  
without prior written permission is prohibited  
except as allowed under the copyright laws.

Product of Singapore  
January 2005

Manual Part Number  
5990-8844

