

Appendix A: Configuring the Router to Boot from Compact Flash

Updating the Boot Process

If your router was shipped before July 2005, your router can be updated to boot, by default, from compact flash. Follow these steps:

1. Update the router Boot ROM to version J02_02A.biz or later.
2. Load and boot from the updated Boot ROM file (J02_02A.biz or later).
3. Make any necessary changes to the router's configuration and save the running-config file.

```
ProCurve>  
ProCurve> enable  
ProCurve# write memory
```

You now have a current startup-config in flash.

4. Rename the current software file to SROS.BIZ. *The file name must be in all capital letters.*

Syntax: copy flash J0X_0X.biz flash SROS.BIZ

```
ProCurve# copy flash J06_03.biz flash SROS.BIZ
```

5. Copy the SROS.BIZ file and the startup-config file to compact flash. If you are not currently using a compact flash card, go to step 6.

Syntax: copy flash startup-config cflash startup-config

Syntax: copy flash J0X_0X.biz cflash SROS.BIZ

6. Change the primary boot path to boot from compact flash first, and from flash as a backup.

```
ProCurve# configure terminal  
ProCurve(config)# boot system cflash SROS.BIZ flash SROS.BIZ  
ProCurve(config)# boot config cflash startup-config flash startup-config
```

Appendix A: Configuring the Router to Boot from Compact Flash
Updating the Boot Process