

Numerics

- 05.00.00 Software Release 9-11
- 05.2.00 Software Release 9-11
- 1000BaseSx 6-10
- 100BaseFx Ports 6-10
- 9304M Routing Switch 2-9
- 9308M Routing Switch 2-8

A

- Access levels 2-12
- Access, CLI 2-21
- Address Assignment
 - AppleTalk 16-1
- Aging, dynamic port 17-36
- Air Flow 2-15
- Air Flow, Caution 2-3
- Alarm (RMON Group 3) A-3
- Ambient Temperature 2-3
- Ampere Ratings 2-3
- AppleTalk
 - address assignment 16-1
 - command line interface 16-4
 - Components Supported 16-3
 - configuring routing 16-4
 - enabling 16-4
 - filtering zones and networks 16-11
 - network components 16-1
 - non-seed router, configuring 16-8
 - overview 16-1
- AppleTalk Cable VLAN 17-1, 17-32
 - dynamic port add 17-35
- ARP 17-46
 - aging period 9-7
 - global static entry 9-12
 - proxy 9-9
 - static, maximum entries 9-12
 - undeliverable 9-3

Assigning

- interfaces 10-10
- IP Address 2-13
- IPX Addresses 15-4
- password 2-12
- RIP Filters 15-7
- SAP Filters 15-10

Assigning Forward Filters 15-5

- Authentication Method
 - access denied 2-44
 - list 2-41
 - values 2-43

B

- BGP4 9-7
 - IP Route Table 9-1
- Boot Command, executable 4-2
- Boot Sequence
 - modifying B-39
- BootP Relay Server
 - maximum hops 9-6
- Broadcast Forwarding 9-9
- Broadcast Leaks 17-10

C

- Cable
 - crossover 2-20
 - length 2-19
 - Straight-through 2-10, 2-20
- Caution, Air Flow 2-3
- Caution, Circuit Overload 2-3
- Caution, grounding 2-3
- Caution, Power Cord 2-3
- Caution, Power Sockets 2-17
- Caution, Powering On 2-17
- Caution, Redundant Power Supply 2-2, 2-7
- CLI
 - use during setup 2-10
- CLI Access 2-21

-
- CLI Command Structure B-37
 - CLI Commands
 - summary B-40
 - Command Line Interface
 - AppleTalk 16-4
 - See also CLI. 2-10
 - Commands
 - All Levels (summary listing) B-63
 - CONFIG Commands B-8
 - DVMRP Router Level (summary listing) B-54
 - Global Level B-83
 - global level (summary listing) B-43
 - interface level (summary listing) B-47
 - OSPF Router Level (summary listing) B-55
 - PIM Router Level (summary listing) B-56
 - RIP (IP) Router Level (summary listing) B-57
 - VLAN Level (summary listing) B-61, B-62
 - CONFIG Interface Commands
 - IP Tunnel Level (summary listing) B-50
 - CONFIG Level 2-12
 - Configuration Changes
 - saving B-38
 - Configuration File
 - downloading and uploading 4-3
 - Configuration, saving changes B-38
 - configurations
 - viewing A-7
 - Configuring
 - AppleTalk Routing 16-4
 - IGMP 11-2
 - IP 9-3
 - IP and IP/RIP 9-3
 - IP Multicasting Protocols 11-1
 - IP Tunnel 11-20
 - IPX 15-2
 - non-seed AppleTalk router 16-8
 - port-based VLAN 17-13
 - SRP 14-1
 - VLAN 17-47
 - VLAN rules summary 17-11
 - VRRP 13-2
 - Connection, Serial 2-1
 - Connections 2-20
 - Connectors, Module 2-18
 - Console Attachment 2-10
 - Console Settings 2-10
 - Conventions
 - manual 1-1
 - Cooling 2-4
 - D**
 - Data Link Support (AppleTalk) 16-4
 - DEFAULT VLAN 17-13
 - DEFAULT-VLAN 17-5
 - Defining
 - Forward Filters 15-5
 - Maximum SAP and RIP Route Entries 15-12
 - RIP Filters 15-7
 - SAP Filters 15-10
 - Desktop Installation 2-15
 - Diagnostic Error Codes for TFTP Transfers 4-5
 - Downloading
 - to a TFTP Server 4-3
 - to a TFTP server 4-1
 - DVMRP
 - configuring 11-1
 - DVMRP Multicasts
 - initiation on a network 11-11
 - Dynamic IPX Configuration 15-2
 - E**
 - EMC Regulatory Statements xii
 - Enabling
 - AppleTalk 16-4
 - IPX 15-2
 - PIM on the Router 11-20
 - SRP on the Router 14-6
 - VRRP on the Router 13-8
 - Enabling IP/RIP 9-4
 - Encapsulation Format, Modify 9-26
 - Erasing image and configuration files 4-6
 - Error Codes for TFTP Transfers 4-5
 - Event (RMON Group 4) A-3
 - EXEC Commands
 - Privileged Level B-69
 - privileged level (summary listing) B-41
 - User Level B-66
 - Executable Boot Command 4-2
 - F**
 - Filter
 - defining IP/RIP Route 9-21
 - defining redistribution 9-23, 9-24
 - IP and IP/RIP 9-13
 - IP, by protocol 9-14
 - route filter maximum 9-21
 - route filter port assignment 9-22
 - Filtering
 - AppleTalk Zones and Networks 16-11
 - Forward Filters
 - defining and assigning 15-5
 - G**
 - Getting Help 1-3
 - Global CONFIG Level 2-13
 - Global IP and IP/RIP Parameters 9-5
 - Grafts to a Multicast Tree 11-6, 11-13
 - Grounding ii, 2-3
 - H**
 - Handles, Warning 2-1, 2-3
 - Help
 - getting 1-3
 - History (RMON Group 2) A-2
 - Hold Downs 9-2
 - Hop Count
 - limit 9-2
 - Hop Count Limit 9-2
-

- Hot Swap
 - modules 2-5
 - redundant power supply 2-6

I

- ICMP Host Unreachable message 9-3
- IGMP
 - configuring 11-2
- Image (software)
 - downloading and uploading 4-1
- Initiating DVMRP Multicasts on a Network 11-11
- Initiating PIM Multicasts on a Network 11-4
- Installation
 - desktop 2-15
 - location and clearance 2-4
 - precautions 2-3
 - summary of 2-2
- Installing a System 2-2
- Integrated Switch Routing 17-3
- Interfaces
 - assigning 10-10
- IP
 - access policies 9-14, 9-19
 - access policies, to ports 9-19
 - access policy, wildcard 9-17
 - advertise IP/RIP routes 9-2
 - ARP, static, maximum entries 9-12
 - assigning address 9-4
 - configuring 9-3
 - configuring IP and IP/RIP 9-3
 - enabling IP/RIP 9-4
 - encapsulation format, modify 9-26
 - encapsulation format, use 9-26
 - filter 9-14
 - filter, backward compatibility 9-14, 9-19
 - filter, defining neighbors
 - Filter
 - defining neighbors 9-23
 - filter, defining redistribution 9-23, 9-24
 - filter, defining route filter 9-21
 - filter, maximum routes 9-21
 - filter, port assignment 9-22
 - filtering by protocol 9-14
 - global IP and IP/RIP parameters 9-5
 - hold downs 9-2
 - hop 9-1
 - hop count limit 9-2
 - interface parameters, modify 9-26
 - IP and IP/RIP filters 9-13
 - IP/RIP protocol, described 9-1
 - learn IP/RIP routes 9-2
 - maximum number of routes 9-1
 - network mask 9-4
 - poison reverse updates 9-2
 - QoS 9-17
 - RARP, maximum entries 9-12

- RIP types 9-1
- split horizons 9-2
- static route 9-11
- TCP and UDP ports 9-15

- IP Address
 - assigning 2-1, 2-13, 9-4
- IP Multicasting Protocols
 - configuring 11-1
- IP sub-net VLAN 17-1
- IP Tunnel
 - configuring 11-20
- IP/RIP Routes
 - advertise 9-2
 - learn 9-2
- IPX
 - assigning addresses 15-4
 - configuring 15-2
 - dynamic configuration 15-2
 - enabling 15-2
- IPX network VLAN 17-1
- IRDP 9-8
- ISR 17-3, 17-13

L

- LAN Connections 2-20
- Lasers
 - IEC compliance xii
- Layer 2 Port-Based VLAN 17-1
- Layer 3 Protocol VLAN 17-1, 17-3
- Layer 4, QoS 9-17
- LED Behavior 2-9
- Lifting, warning 2-1
- Load Sharing 9-8

M

- Manual nomenclature 1-1
- Mask, Network 2-1
 - See also Network Mask. 9-10
- Maximum Transmission Unit
 - defined 9-27
 - modify 9-27
- Metric (default)
 - modifying for redistribution 10-19
- Modify Boot Sequence B-39
- Modifying
 - Boot Sequence B-39
 - default metric for redistribution 10-19
 - OSPF compliance setting 10-28
 - OSPF default port parameters 10-28
- Module
 - installing 2-4
 - removing 2-4
- Mounting
 - air flow 2-15
 - rack mount 2-16, 2-17
 - warning 2-15
- MTU 9-27

-
- Multicast Terms 11-1
 - Multicast Tree
 - grafts 11-6, 11-13
 - pruning 11-4, 11-12
 - Multiple Track Ports for Virtual Interfaces
 - configuring 14-12
 - N**
 - Navigating between Command Levels B-36
 - Network Components
 - AppleTalk 16-1
 - Network Connections, Troubleshooting 2-20
 - Network Layer Support (AppleTalk) 16-4
 - Network Mask 2-1, 9-4
 - prefix format 9-10
 - O**
 - On-going CLI Access 2-21
 - Operating Temperature 2-3
 - OSPF 9-7, 9-8
 - modifying port parameters 10-28
 - overview 10-1
 - Parameters 10-6
 - RFC 1583 Compliant 10-5
 - P**
 - Password 2-12
 - 2-13
 - Password, Lost 2-13
 - Path Cost 17-20
 - Physical Dimensions 6-13
 - PIM
 - configuring 11-1
 - enabling on the router 11-20
 - PIM DM 11-1
 - PIM Multicasts
 - initiating on a network 11-4
 - Pinouts
 - serial port 2-11, 2-12
 - Poison Reverse Updates 9-2
 - Port
 - logical 17-3
 - TCP 9-15
 - UDP 9-15
 - Port statistics
 - viewing A-10
 - Port Statistics, View of A-10
 - Port Trunk
 - See also Trunk Group. 17-11
 - Port-Based VLAN Limit 17-2, 17-6
 - Port-Based VLAN, STP Domain 17-13
 - Power Cord 2-9
 - caution 2-3, 2-17
 - Power Supply
 - See Redundant Power Supply. 2-7
 - Precautions
 - installation 2-3
 - Privileged EXEC Level 2-13
 - Privileged EXEC level 2-12
 - Privileged Level EXEC commands B-6
 - Prompt, customizing 2-11
 - Protocol-Based VLANs B-201
 - Protocol-independent Multicast Dense Mode 11-1
 - Proxy ARP 9-9
 - Pruning a Multicast Tree 11-4, 11-12
 - Q**
 - QoS 9-17
 - R**
 - Rack Mounting 2-3, 2-16, 2-17
 - warning 2-3, 2-15
 - Rack, Loading 2-3
 - RADIUS
 - configuring 2-39
 - limits 2-37, 2-39, 2-41, 2-42
 - RARP 9-9
 - global static entry 9-12
 - maximum entries 9-12
 - Redistribution
 - modifying default metric 10-19
 - Redundant Management
 - maximum number of IP routes 9-1
 - Redundant Power Supply
 - Caution 2-2
 - installing 2-6
 - removing 2-7
 - Regulatory Statements xii
 - RIP
 - See also IP. 9-1
 - RIP filters
 - assigning and defining 15-7
 - RIP route entries
 - defining maximum 15-12
 - RIP Types 9-1
 - RMON agent A-1
 - Route, Static 9-3
 - Router DVMRP Level B-23
 - Router OSPF Level B-24
 - Router PIM Level B-26
 - Router RIP Level B-27, B-31
 - Routing
 - AppleTalk VLANs with virtual interfaces 16-15
 - Routing Between VLANs 17-12, 17-23
 - RPS
 - See Redundant Power Supply 2-2
 - S**
 - SAP Filters
 - assigning and defining 15-10
 - SAP route entries
 - defining maximum 15-12
 - Saving Configuration Changes B-38
 - Saving image and configuration files 4-6
-

-
- Security
 - configuring RADIUS 2-39
 - IP access policies 9-14
 - Seed and Non-Seed Routers (AppleTalk) 16-2
 - Serial Connection 2-1
 - Serial Port Pinouts 2-11, 2-12
 - Service ii
 - Session Layer Support (AppleTalk) 16-3
 - Settings, Terminal 2-10
 - Shock Hazard, Warning 2-18
 - Slot Cover Plates, Air Flow 2-3
 - SNMP
 - traps, enable broadcast forwarding 9-10
 - Software Image
 - downloading and uploading 4-1
 - Spanning Tree
 - See also STP. 17-2
 - Split Horizons 9-2
 - SRP
 - configuring 14-1
 - enabling on the router 14-6
 - multiple VLANs 17-45
 - Support on Virtual Interfaces 14-12
 - Static IP Route 9-3, 9-11
 - Statistics (RMON Group 1) A-1
 - STP 17-7, 17-13
 - bridge, VLAN 17-20
 - default setting 17-7
 - enable on VLAN 17-19
 - single instance 17-2
 - STP statistics
 - viewing A-11
 - Summary of CLI Commands B-40
 - Super User 2-12
 - Supported Components
 - AppleTalk 16-3
 - System
 - installation 2-2
 - unpacking 2-1
 - System Information, display of A-7
- T**
- TACACS/TACACS+ limits 2-37, 2-41, 2-42
 - Tagged VLAN 17-6
 - TCP port 9-15
 - Temperature 2-3
 - Terminal Settings 2-10
 - TFTP Server
 - downloading and uploading 4-1, 4-3
 - TFTP Transfers, error codes 4-5
 - Time-To-Live Threshold 9-7
 - Trace Route A-5
 - Troubleshooting Network Connections 2-20
 - Trunk Group
 - ports in a VLAN 17-11, 17-13
- U**
- UDP port 9-15
 - Unpacking a System 2-1
 - Uploading
 - to a TFTP server 4-1, 4-3
 - User EXEC level 2-12
 - UTP Crossover Cable 2-20
- V**
- Viewing
 - Configurations A-7
 - Port Statistics A-10
 - STP Statistics A-11
 - System Information A-7
 - Virtual Interface 17-3, 17-8
 - defined 17-8
 - Virtual Interfaces
 - configuring multiple track ports 14-12
 - routing AppleTalk VLANs 16-15
 - SRP support 14-12
 - VLAN
 - 802.1q tagging 17-6
 - AppleTalk Cable 17-1, 17-4, 17-32
 - AppleTalk limit 17-9
 - AppleTalk protocol 17-4
 - ARP 17-46
 - bridge STP parameters 17-20
 - broadcast leaks 17-10
 - config rules summary 17-11
 - configuring 17-47
 - default VLAN 17-5
 - default VLAN ID 17-13
 - displaying specific port information 17-49
 - dynamic port 17-9, 17-35, 17-36, 17-40, 17-42
 - ID 17-6, 17-13, 17-41
 - integrated switch routing 17-3
 - IP protocol 17-4
 - IP subnet 17-1, 17-4
 - IPX network 17-1, 17-4
 - IPX protocol 17-4
 - IPX, dynamic port 17-43
 - ISR 17-3
 - layer 2, port-based 17-1, 17-2
 - layer 3, protocol 17-1, 17-3
 - multiple instance of STP 17-7
 - multiple membership, rules 17-11
 - multiple, same IP subnet address 17-44, 17-45
 - operation 17-1
 - port-based 17-11, 17-13, 17-17
 - port-based, limit 17-6
 - port-based, STP domain 17-13
 - priority 17-19
 - protocol, limit 17-2, 17-11
 - protocol-based 17-21, 17-35
 - routing between 17-12
 - rules 17-11
 - single instance of STP 17-2
 - static ports 17-9
 - STP default setting 17-7
 - STP, enable 17-19
-

- subnet or network limit 17-11
- trunk group ports 17-11
- trunk group, assigning ports 17-13
- types 17-1
- virtual interface 17-3, 17-8
- virtual interface, defined 17-8
- virtual interface, routing 17-23

VLAN Level B-32

VRRP

- configuring 13-2
- enabling on the router 13-8
- multiple VLANs 17-45

W

Warning

- handles 2-1, 2-3
- rack or cabinet secured 2-3
- system placement in rack 2-15
- weight 2-1, 2-3

Warning, Electrical Shock Hazard, Warning 2-18

Warranty ii

Weight

- warning 2-3, 2-15, 2-18

Z

Zone Information Protocol (ZIP) 16-3