

Firmware Release Note



Model : SL-C460FW	Date :	May 19, 2016
--------------------------	---------------	---------------------

Version	Category	Change Description
V3.00.02.06 (7-Apr, 2014)	Fix Defect	Fixed the problem that Android 4.3 (JB) mobile device can't connect when wifi direct connection was max.
		Fixed NFC connection problem.
V3.00.02.07 (15-Apr, 2014)	Fix Defect	Improvement of Color to Mono Printing Problem
		Fixed Google Cloud Print issue. ("chunked" data control)
		Changed the target temperautre for improvement of Naonodust
V3.00.02.13 (10-Oct, 2014)	Fix Defect	Try to printing JPEG files via AirPrint on iOS8, printer is rebooting
V3.00.02.16 (22-Dec, 2014)	Fix Defect	Fix USB PC printing blocking problem
V3.00.02.21 (4-Jan, 2016)	New Func.	Apply to Samsung Cloud Print
		Apply new font in PCL5, PCL6
	Fix Defect	[Google Cloud Print] Print & deregistration does not work properly
		Improve Fax transimistion on VoIP line(for Israel 'HOT' line)
		Fix ADF color scan issue(yellow color drop)
		Fix Print quality(pullation) issue

※ Note

- Please do not turn off the printer and your computer until firmware update finishes.
- If you are using USB connection, disconnect all other USB printers from the PC.
- The firmware update you are about to install has been tested for compatibility with Samsung toner cartridge products ONLY.

Installing The upgrade may cause a non-Samsung toner cartridge to malfunction.

- Do not run your printer during the firmware update.(Do not have any print job)

How to update the firmware using a USB cable.

1. Make sure that the machine is connected to the PC with a USB cable
2. Check the currently f/w version of your printer.

If the f/w version is V3.xx.01.xx, execute a upgrade patch file as below.

2-1) Execute C46xFW_Upgrade_Patch.exe

And then patch rom will be download on the machine via USB or Network port

2-2) Please wait until green LED is ON.(About 2 minute)

* Reference

- ① Red LED Blinking for about 30 sec
- ② Green LED ON for 30 sec
- ③ Red LED Blinking for 60 sec
- ④ Green LED ON

Go on the next step

If the f/w version is V3.xx.02.xx, go on No. 3

3. Set the firmware upgrade mode 'ON'
 - 1) Press "Menu > # > 1 > 9 > 3 > 4" on the control panel continuously.
 - 2) Menu > Data Setup > F/W Upgrade > ON
4. Drag a f/w file 'C460FW_V3.00.02.21.hd' and Drop down it on usblast2.exe
5. The firmware update will start.

Once the firmware update is complete, the machine will be rebooted automatically.

Updating from the Network

1. Go to the SyncThruWeb Service (SWS) main home page.

Login as Admin in SyncThruWeb Service.

NOTE: Login using the Administrator ID and Password established during initial machine setup.

2. Click [Maintenance] on the top menu.

And then click [Firmware Upgrade] or Application Management > Application

3. Click Add button
4. Click [Browse]. Choose installation file by browsing file system. And click OK button
5. The uploading step will start. After this step, next step will be started automatically.
6. The firmware update will start.
7. Once the f/w update is complete, the machine power-off and power-on automatically.