

Firmware Release Note



Model : CLX-3300, 3305, 3306, 3305W, 3306W	Date :	June 10, 2016
---	---------------	----------------------

Version	Category	Change Description
V3.00.02.10 (4-Sep, 2014)	Fix Defect	Fix the Printer USB device recognition failure issue
V3.00.02.17 (24-Dec, 2014)	Fix Defect	Try to printing JPEG files via AirPrint on iOS8, printer is rebooting
		Fix USB PC printing blocking problem
V3.00.02.20 (16-May, 2016)	Add Func.	Apply to Samsung Cloud Print
	Fix Defect	Improve Fax transimition on VoIP line (For Israel 'HOT' Line)
		[Google Cloud Print] Print & deregistration doesn't work properly

※ Note

- Please do not turn off the printer and your computer until firmware update finishes.
- If you are using USB connection, disconnect all other USB printers from the PC.
- The firmware update you are about to install has been tested for compatibility with Samsung toner cartridge products ONLY.

Installing The upgrade may cause a non-Samsung toner cartridge to malfunction.

- Do not run your printer during the firmware update.(Do not have any print job)

How to update the firmware using a USB cable.

1. Make sure that the machine is connected to the PC with a USB cable
2. Check the currently f/w version of your printer.

If the f/w version is V3.xx.01.xx, execute a upgrade patch file as below.

2-1) Execute CLX3305W_Upgrade_Patch.exe

And then patch rom will be download on the machine via USB

2-2) Please wait until green LED is ON.(About 2 minute)


* Reference

- ① Red LED Blinking for about 30 sec
- ② Green LED ON for 30 sec
- ③ Red LED Blinking for 60 sec
- ④ Green LED ON

2-3) Go on to the next step(No.3)


If the f/w version is V3.xx.02.xx, Go on to the next step(No.3)

3. Drag 'SWUPGRADE_ON.prn' and drop down it on usblist2.exe.



4. Drag the firmware file(*.hd) and Drop down it on usblist2.exe.

And then, firmware update will be started automatically.



How to update the firmware for a network connected printer.

1. Open Internet Explorer and enter the IP address of your printer.
2. Go to the SyncThruWeb Service (SWS) main home page.

Login as Admin in SyncThruWeb Service.

NOTE: Login using the Administrator ID and Password established during initial machine setup.

3. Click [Maintenance] on the top menu.

And then click [Firmware Upgrade] or Application Management > Application

4. Click Add button

5. Click [Browse].

Choose installation file by browsing file system. And click OK button

6. The firmware update will start.

Once the f/w update is complete, the machine power-off and power-on automatically.