

Firmware Release Note

Model : SL-M2060FW(for Fax model)	Date :	October 1, 2018
--	---------------	------------------------

Version	Category	Change Description
V3.xx.01.16 (21-Apr, 2014)	Fix Deffect	Improve highlight and back ground image quality.
V3.xx.01.17 (30-Jul, 2014)	Fix Deffect	Fix the Google Cloud Print issues
	Fix Deffect	Improve the CIS motor noise.
V3.xx.01.20 (15-Oct,2014)	Fix Deffect	Try to printing JPEG files via AirPrint on iOS8, The machine is rebooting
V3.xx.01.22 (16-Jan, 2015)	Add Func.	Apply the Google Cloud Print 2.0 feature
V3.xx.01.24 (21-Dec,2015)	Add Func.	Apply new font in PCL 5, PCL 6
V3.xx.01.25 (21-Apr,2016)	Add Func.	Apply to Samsung Cloud Print
	Fix Deffect	Fix reboot repeatedly
		Fix network connection fail after sleep mode
		Improve Fax transimition on VoIP line
V3.xx.01.26 (24-May,2016)	Fix Deffect	Improve Paper JAM problem
V3.xx.01.27 (3-Jun,2016)	Fix Deffect	Fix sometimes device doesn't wake up from sleep mode
V3.xx.01.33 (27-Feb,2018)	Fix Deffect	Fix printing quality(background) issue
V3.xx.01.37 (1-Oct, 2018)	Fix Deffect	Fix printing quality(dim and dirty printing) issue

※ Note

- Please do not turn off the printer and your computer until firmware update finishes.
- If you are using USB connection, disconnect all other USB printers from the PC.
- The firmware update you are about to install has been tested for compatibility with Samsung toner cartridge products ONLY.

Installing The upgrade may cause a non-Samsung toner cartridge to malfunction.

- Do not run your printer during the firmware update.(Do not have any print job)

How to update the firmware using a USB cable.

1. Make sure that the machine is connected to the PC with a USB cable.
2. Drag the firmware file(*.hd) and Drop down it on usblast2.exe.

And then, firmware update will be started automatically.



3. The firmware update will start.

Once the firmware update is complete, the machine will be rebooted automatically.