

<b>GETTING STARTED.....</b>	<b>1-1</b>
INTRODUCTION .....	1-1
AUDIENCE .....	1-1
MANUAL NOMENCLATURE .....	1-1
RELATED PUBLICATIONS .....	1-1
HOW TO GET HELP .....	1-1
<b>INSTALLATION.....</b>	<b>2-1</b>
UNPACKING A SYSTEM .....	2-1
PACKAGE CONTENTS .....	2-1
GENERAL REQUIREMENTS .....	2-1
INSTALLATION PROCEDURES .....	2-2
SUMMARY .....	2-2
INSTALLATION PRECAUTIONS .....	2-3
1. PREPARING THE INSTALLATION SITE .....	2-4
CABLING INFRASTRUCTURE .....	2-4
INSTALLATION LOCATION .....	2-4
2. INSTALLING (OR REMOVING) OPTIONAL MODULES .....	2-4
INSTALLING MODULES .....	2-4
REMOVING MODULES .....	2-5
3. INSTALLING (OR REMOVING) REDUNDANT POWER SUPPLIES .....	2-6
INSTALLING POWER SUPPLIES .....	2-6
REMOVING POWER SUPPLIES .....	2-6
4. VERIFYING PROPER OPERATION .....	2-8
5. ATTACHING A PC OR TERMINAL .....	2-9
6. ASSIGNING A PERMANENT PASSWORD .....	2-10
7. ASSIGNING IP ADDRESSES .....	2-11
8. MOUNTING THE ROUTING SWITCH .....	2-11
DESKTOP INSTALLATION .....	2-11
RACK MOUNT INSTALLATION .....	2-11
9. CONNECTING POWER TO THE ROUTING SWITCH .....	2-13
10. CONNECTING NETWORK DEVICES .....	2-13
NEXT STEPS .....	2-15

<b>UPDATING SOFTWARE IMAGES AND CONFIGURATION FILES .....</b>	<b>3-1</b>
DOWNLOADING AND UPLOADING A SOFTWARE IMAGE TO A TFTP SERVER .....	3-1
EXECUTABLE BOOT COMMAND .....	3-2
DOWNLOADING AND UPLOADING A CONFIGURATION FILE TO A TFTP SERVER .....	3-3
UPLOADING (SAVING) OR DOWNLOADING A CONFIGURATION FILE TO OR FROM A TFTP SERVER .....	3-3
DIAGNOSTIC ERROR CODES FOR TFTP TRANSFERS .....	3-4
ERROR CODE TROUBLESHOOTING .....	3-5
SAVING OR ERASING IMAGE AND CONFIGURATION FILES .....	3-5
<b>SOFTWARE OVERVIEW .....</b>	<b>4-1</b>
FEATURE SUMMARY .....	4-1
DOMAIN NAME SERVER (DNS) RESOLVER .....	4-2
EXECUTABLE BOOT COMMAND .....	4-2
INTEGRATED SWITCH ROUTING (ISR) .....	4-2
IP MULTICAST ROUTING .....	4-3
IP TUNNELING .....	4-3
LAYER 2, LAYER 3 IP/IPX AND LAYER 4 HARDWARE SWITCHING .....	4-3
LAYER 2 MAC FILTERING .....	4-3
LAYER 3 PROTOCOL FILTERING .....	4-3
MONITORING TOOLS .....	4-3
MULTI-HOMING .....	4-4
NETWORK MANAGEMENT .....	4-4
POLICY-BASED VLANs .....	4-5
PROTOCOL SUPPORT .....	4-6
REDUNDANT ROUTER SUPPORT FOR IP .....	4-6
SELECTABLE CLASS OF SERVICE (COS) .....	4-6
SNTP CLOCKING .....	4-7
SPANNING TREE PROTOCOL .....	4-7
STATIC ENTRY SUPPORT .....	4-7
TRUNK GROUPS .....	4-7
UDP HELPER .....	4-7
<b>HARDWARE OVERVIEW .....</b>	<b>5-1</b>
HP 9304M AND HP 9308M ROUTING SWITCHES .....	5-1
SYSTEM ARCHITECTURE .....	5-5
PHYSICAL VIEW .....	5-5
AC POWER CONNECTOR .....	5-5
BUFFERING .....	5-5
FANS .....	5-5
LEDs .....	5-6
PORTS .....	5-7
PROCESSORS .....	5-7
POWER SUPPLY .....	5-7
RESET BUTTON .....	5-7
STANDARDS COMPLIANCE .....	5-8
RFC AND PROTOCOLS .....	5-8
DRAFTS .....	5-9
PHYSICAL SPECIFICATIONS .....	5-9
ELECTRICAL SPECIFICATIONS .....	5-9
PHYSICAL DIMENSIONS .....	5-9
OPERATING ENVIRONMENT .....	5-9
EMC COMPLIANCE .....	5-10
SAFETY .....	5-10

---

<b>NETWORK APPLICATIONS .....</b>	<b>6-1</b>
NETWORK APPLICATIONS .....	6-1
ROUTING SWITCH APPLICATIONS .....	6-1
<b>CONFIGURING BASIC AND ADVANCED FEATURES.....</b>	<b>7-1</b>
CONFIGURING BASIC SYSTEM PARAMETERS .....	7-2
ENTERING SYSTEM ADMINISTRATION INFORMATION .....	7-3
ASSIGNING IP SUB-NET ADDRESSES .....	7-4
ENABLING OR DISABLING SNMP OPERATION .....	7-5
ASSIGNING A SNMP STATION TO COLLECT TRAPS .....	7-5
MODIFYING SNMP TRAPS GENERATED .....	7-7
MODIFYING THE COMMUNITY STRING .....	7-9
DEFINING A MAC ADDRESS FILTER .....	7-9
SETTING THE SYSTEM CLOCK .....	7-10
ESTABLISHING A REFERENCE NETWORK TIME PROTOCOL (NTP) SERVER .....	7-11
ENABLING PORT-BASED AND LAYER 3 PROTOCOL VLANs .....	7-12
ENABLING OR DISABLING PROTOCOLS .....	7-13
ENABLING OR DISABLING THE SPANNING TREE PROTOCOL (STP) .....	7-13
ENABLING IEEE 802.1Q VLAN TAGGING .....	7-14
ENABLING OR DISABLING TELNET .....	7-14
MODIFYING TELNET TIMEOUT .....	7-14
MODIFYING THE TELNET PASSWORD .....	7-15
ENABLING OR DISABLING LAYER 2 SWITCHING .....	7-15
ADDING OR DELETING MODULES .....	7-16
MODIFYING SYSTEM PARAMETERS DEFAULT SETTINGS .....	7-17
MODIFYING EVENTS COLLECTED IN THE SYSTEM LOG .....	7-19
ENABLING OR DISABLING WEB MANAGEMENT ACCESS .....	7-21
ASSIGNING RADIUS AUTHENTICATION SUPPORT .....	7-21
CONFIGURING PORT PARAMETERS .....	7-26
MODIFYING PORT SPEED .....	7-27
ASSIGNING A PORT NAME .....	7-28
MODIFYING PORT DUPLEX MODE .....	7-28
DISABLE OR ENABLE PORT STATUS .....	7-28
ENABLE OR DISABLE FLOW CONTROL .....	7-29
ENABLE OR DISABLE AUTO-NEGOTIATE .....	7-29
MODIFY PORT PRIORITY (QOS) .....	7-30
ENABLE OR DISABLE PORT MONITORING .....	7-31
LOCKING A PORT TO RESTRICT ADDRESS ACCESS .....	7-31
ASSIGN IEEE (802.1Q) TAGGING TO A PORT .....	7-32
ENABLING MONITORING ON A PORT .....	7-32
CONFIGURING STP .....	7-34
CONFIGURING STATIC MAC ENTRIES .....	7-37
TRUNK GROUPS .....	7-38
OVERVIEW .....	7-38
TRUNK GROUP RULES .....	7-39
TRUNK GROUP CONFIGURATION AND START-UP NOTES .....	7-39
<b>CONFIGURING IP AND IP/RIP.....</b>	<b>8-1</b>
OVERVIEW OF IP/RIP .....	8-1
IP/RIP FEATURES .....	8-1
CONFIGURING IP AND IP/RIP .....	8-3
ENABLING IP/RIP .....	8-4
ASSIGNING IP ADDRESSES .....	8-4
MODIFYING GLOBAL IP AND IP/RIP PARAMETERS (OPTIONAL) .....	8-5

---

DEFINING STATIC IP ROUTES .....	8-9
ASSIGNING STATIC ARP AND RARP ENTRIES (OPTIONAL) .....	8-10
ASSIGNING IP AND IP/RIP FILTERS .....	8-12
DEFINING IP FILTERS (OPTIONAL) .....	8-12
ASSIGNING IP FILTER GROUPS (OPTIONAL) .....	8-14
DEFINING IP/RIP FILTERS .....	8-16
ASSIGNING IP/RIP FILTER GROUPS GLOBALLY .....	8-17
DEFINING IP/RIP NEIGHBOR FILTERS .....	8-18
ASSIGNING IP/RIP FILTER GROUPS TO INTERFACES .....	8-19
DEFINING REDISTRIBUTION FILTERS .....	8-20
MODIFY IP AND IP/RIP INTERFACE PARAMETERS (OPTIONAL) .....	8-22
IP INTERFACE PARAMETERS .....	8-22
IP/RIP INTERFACE PARAMETERS (OPTIONAL) .....	8-24
MODIFY GLOBAL IP/RIP PARAMETERS .....	8-25
ENABLING OR DISABLING REDISTRIBUTION .....	8-26
MODIFYING THE REDISTRIBUTION GLOBAL DEFAULT METRIC .....	8-26
ENABLING IP/RIP DEFAULT ROUTE LEARNING AND ADVERTISING .....	8-27
CONFIGURING DOMAIN NAME SERVER (DNS) RESOLVER .....	8-28
INITIATING A TRACE ROUTE .....	8-29
CONFIGURING UDP HELPER (OPTIONAL) .....	8-31
<b>CONFIGURING OSPF .....</b>	<b>9-1</b>
OVERVIEW OF OSPF .....	9-1
DESIGNATED ROUTERS IN MULTI-ACCESS NETWORKS .....	9-2
DESIGNATED ROUTER ELECTION .....	9-3
OSPF RFC 1583 AND 2178 COMPLIANT .....	9-4
DYNAMIC OSPF ACTIVATION AND CONFIGURATION .....	9-5
CONFIGURING OSPF .....	9-6
CONFIGURATION RULES .....	9-6
OSPF PARAMETERS .....	9-6
ENABLING OSPF ON THE ROUTER .....	9-7
ASSIGNING OSPF AREAS .....	9-7
ASSIGNING AN AREA RANGE (OPTIONAL) .....	9-8
ASSIGNING INTERFACES TO AN AREA .....	9-9
MODIFY PORT DEFAULTS .....	9-10
ASSIGN VIRTUAL LINKS .....	9-12
ENABLING REDISTRIBUTION .....	9-16
DEFINING REDISTRIBUTION FILTERS .....	9-16
MODIFY DEFAULT METRIC FOR REDISTRIBUTION .....	9-19
MODIFY REDISTRIBUTION METRIC TYPE .....	9-20
MODIFY EXTERNAL LSDB LIMIT .....	9-20
MODIFY EXIT OVERFLOW INTERVAL .....	9-21
MODIFY OSPF TRAPS GENERATED .....	9-21
MODIFY OSPF STANDARD COMPLIANCE SETTING .....	9-23
<b>CONFIGURING IP MULTICAST PROTOCOLS .....</b>	<b>10-1</b>
OVERVIEW OF IP MULTICASTING .....	10-1
MULTICAST TERMS .....	10-1
PIM OVERVIEW .....	10-2
INITIATING PIM MULTICASTS ON A NETWORK .....	10-2
PRUNING A MULTICAST TREE .....	10-2
GRAFTS TO A MULTICAST TREE .....	10-4

---

CONFIGURING PIM .....	10-5
ENABLING PIM ON THE ROUTER AND AN INTERFACE .....	10-5
MODIFYING PIM GLOBAL PARAMETERS .....	10-6
DVMRP OVERVIEW .....	10-10
INITIATING DVMRP MULTICASTS ON A NETWORK .....	10-10
PRUNING A MULTICAST TREE .....	10-10
GRAFTS TO A MULTICAST TREE .....	10-12
CONFIGURING DVMRP .....	10-13
ENABLING DVMRP ON THE ROUTER AND INTERFACE .....	10-13
MODIFYING DVMRP GLOBAL PARAMETERS .....	10-15
MODIFYING DVMRP INTERFACE PARAMETERS .....	10-18
CONFIGURING AN IP TUNNEL .....	10-21
CONFIGURING IGMP .....	10-23
MODIFYING IGMP QUERY INTERVAL PERIOD .....	10-23
MODIFYING IGMP MEMBERSHIP TIME .....	10-23
<b>CONFIGURING SRP .....</b>	<b>11-1</b>
OVERVIEW OF SRP .....	11-1
SRP SUPPORT ON VIRTUAL INTERFACES .....	11-2
ACTIVE AND STANDBY ROUTERS .....	11-3
TRACK PORTS .....	11-3
INDEPENDENT OPERATION OF RIP AND OSPF .....	11-5
CONFIGURING SRP .....	11-6
CONFIGURATION RULES FOR SRP .....	11-6
ENABLE SRP ON THE ROUTER .....	11-6
ASSIGN VIRTUAL ROUTER IP ADDRESSES .....	11-7
ASSIGNING THE TRACK PORT .....	11-8
ASSIGNING THE ACTIVE ROUTER .....	11-8
MODIFY PORT PARAMETERS (OPTIONAL) .....	11-9
CONFIGURING SRP ON VIRTUAL INTERFACES .....	11-12
<b>CONFIGURING IPX.....</b>	<b>12-1</b>
OVERVIEW OF IPX .....	12-1
MULTIPLE IPX FRAME TYPE SUPPORT PER INTERFACE .....	12-1
CONFIGURING IPX .....	12-1
DYNAMIC IPX CONFIGURATION .....	12-2
ENABLE IPX .....	12-2
ENABLE NETBIOS .....	12-2
ASSIGN IPX NETWORK NUMBER, FRAME TYPE, ENABLE NETBIOS ON AN INTERFACE .....	12-3
DEFINE AND ASSIGN A FORWARD FILTER AND GROUP .....	12-5
DEFINE AND ASSIGN A RIP FILTER AND GROUP .....	12-8
DEFINE AND ASSIGN A SAP FILTER AND GROUP .....	12-10
MODIFY MAXIMUM SAP AND RIP ROUTE ENTRIES .....	12-12
MODIFY RIP AND SAP HOP COUNT INCREMENT .....	12-13
<b>CONFIGURING APPLE TALK .....</b>	<b>13-1</b>
OVERVIEW OF APPLE TALK .....	13-1
ADDRESS ASSIGNMENT .....	13-1
NETWORK COMPONENTS .....	13-1
ZONE FILTERING .....	13-2
NETWORK FILTERING .....	13-3
SEED AND NON-SEED ROUTERS .....	13-3
APPLE TALK COMPONENTS SUPPORTED ON HP ROUTING SWITCHES .....	13-3
SESSION LAYER SUPPORT .....	13-3
TRANSPORT LAYER SUPPORT .....	13-3

---

NETWORK LAYER SUPPORT .....	13-3
DATA LINK SUPPORT .....	13-4
DYNAMIC APPLE TALK ACTIVATION AND CONFIGURATION .....	13-4
CONFIGURING APPLE TALK ROUTING .....	13-5
ENABLE APPLE TALK .....	13-5
CONFIGURING A SEED APPLE TALK ROUTER .....	13-5
SAVING CONFIGURATION CHANGES TO THE INTERFACE .....	13-6
CONFIGURING A NON-SEED APPLE TALK ROUTER .....	13-9
ENABLING APPLE TALK ROUTING AT THE GLOBAL (SYSTEM) LEVEL .....	13-9
ENABLE APPLE TALK ROUTING ON AN INTERFACE .....	13-9
MODIFYING APPLE TALK INTERFACE CONFIGURATIONS .....	13-11
FILTERING APPLE TALK ZONES AND NETWORKS .....	13-12
DEFINING ZONE FILTERS .....	13-12
NETWORK FILTERING .....	13-15
ROUTING BETWEEN APPLE TALK VLANs USING VIRTUAL INTERFACES .....	13-16
CONFIGURING THE VIRTUAL ROUTER INTERFACE .....	13-18
CONFIGURING A PHYSICAL INTERFACE FOR REMOTE ACCESS .....	13-19
CREATING APPLE TALK PROTOCOL VLANs .....	13-24
CONFIGURING THE ROUTER INTERFACES .....	13-25
CONFIGURING THE PHYSICAL INTERFACE FOR REMOTE ACCESS .....	13-26
MODIFYING APPLE TALK GLOBAL PARAMETERS .....	13-27
APPLE TALK ARP RETRANSMIT COUNT .....	13-27
APPLE TALK ARP RETRANSMIT INTERVAL .....	13-27
APPLE TALK GLEAN PACKETS .....	13-28
APPLE TALK QoS SOCKET .....	13-28
APPLE TALK RTMP UPDATE INTERVAL .....	13-28
SHOW COMMANDS FOR APPLE TALK .....	13-31
CLEAR COMMANDS FOR APPLE TALK .....	13-33
<b>CONFIGURING VLANs.....</b>	<b>14-1</b>
OVERVIEW OF POLICY-BASED VLANs .....	14-1
PORT-BASED VLANs .....	14-2
PROTOCOL-BASED VLANs .....	14-2
PROTOCOL VLAN PORT MEMBERSHIP .....	14-2
BROADCAST AND MULTICAST PACKETS WITHIN VLANs .....	14-3
ROUTING BETWEEN VLANs USING VIRTUAL INTERFACES .....	14-3
CONFIGURING PORT-BASED VLANs .....	14-4
CONFIGURATION NOTES AND RULES .....	14-4
CONFIGURING PROTOCOL-BASED VLANs .....	14-10
CONFIGURING IP SUB-NET AND IPX NETWORK VLANs .....	14-14
CONFIGURING PROTOCOL-BASED VLANs WITHIN PORT-BASED VLANs .....	14-20
ROUTING BETWEEN VLANs USING VIRTUAL INTERFACES .....	14-22
<b>NETWORK MONITORING .....</b>	<b>A-1</b>
RMON .....	A-1
SNMP SYSTEM LOG .....	A-4
TRACE ROUTE AND STOP TRACE ROUTE .....	A-5
VIEWING SYSTEM SUMMARY INFORMATION .....	A-7
VIEWING SYSTEM INFORMATION .....	A-8
VIEWING CONFIGURATIONS .....	A-10
VIEWING PORT STATISTICS .....	A-13
VIEWING STP STATISTICS .....	A-14
CLEARING STATISTICS .....	A-15

---

<b>COMMAND LINE INTERFACE COMMANDS.....</b>	<b>B-1</b>
EXEC COMMANDS .....	B-3
USER LEVEL .....	B-3
PRIVILEGED LEVEL .....	B-4
CONFIG COMMANDS .....	B-5
GLOBAL LEVEL .....	B-5
INTERFACE LEVEL .....	B-9
IP TUNNEL LEVEL .....	B-11
ROUTER DVMRP LEVEL .....	B-12
ROUTER OSPF LEVEL .....	B-13
ROUTER PIM LEVEL .....	B-14
ROUTER RIP LEVEL .....	B-15
VLAN LEVEL .....	B-16
ACCESSING THE CLI .....	B-18
NAVIGATING BETWEEN COMMAND LEVELS .....	B-19
CLI COMMAND STRUCTURE .....	B-20
SYNTAX SHORTCUTS .....	B-20
SAVING CONFIGURATION CHANGES .....	B-21
MODIFYING BOOT SEQUENCE .....	B-21
SUMMARY OF CLI COMMANDS .....	B-22
TABLE OF CONTENTS FOR CLI COMMANDS .....	B-23
EXEC COMMANDS- USER LEVEL .....	B-23
EXEC COMMANDS – PRIVILEGED LEVEL .....	B-23
CONFIG COMMANDS - GLOBAL LEVEL.....	B-25
CONFIG COMMANDS – INTERFACE LEVEL.....	B-28
CONFIG INTERFACE COMMANDS – IP TUNNEL LEVEL .....	B-30
CONFIG COMMANDS – DVMRP ROUTER LEVEL .....	B-30
CONFIG COMMANDS – OSPF ROUTER LEVEL.....	B-31
CONFIG COMMANDS – PIM ROUTER LEVEL .....	B-31
CONFIG COMMANDS – RIP (IP/RIP) ROUTER LEVEL .....	B-32
CONFIG COMMANDS – VLAN LEVEL .....	B-32
COMMANDS - ALL LEVELS.....	B-34
CONFIG COMMANDS – INTERFACE LEVEL .....	B-84
CONFIG COMMANDS – IP TUNNEL LEVEL .....	B-103
CONFIG COMMANDS – DVMRP ROUTER LEVEL .....	B-106
CONFIG COMMANDS – OSPF ROUTER LEVEL .....	B-111
CONFIG COMMANDS – PIM ROUTER LEVEL .....	B-119
CONFIG COMMANDS – IP/RIP ROUTER LEVEL .....	B-123
CONFIG COMMANDS – VLAN LEVEL .....	B-129
COMMANDS - ALL LEVELS .....	B-137
<b>SAFETY AND EMC REGULATORY STATEMENTS.....</b>	<b>C-1</b>
SAFETY INFORMATION .....	C-1
GROUNDING .....	C-1
SERVICING .....	C-1
INFORMATIONS CONCERNANT LA SÉCURITÉ .....	C-2
HINWEISE ZUR SICHERHEIT .....	C-3
CONSIDERAZIONI SULLA SICUREZZA .....	C-4
CONSIDERACIONES SOBRE SEGURIDAD .....	C-5
SAFETY INFORMATION (JAPAN) .....	C-6
SAFETY INFORMATION (CHINA) .....	C-7
EMC REGULATORY STATEMENTS .....	C-8
U.S.A. ....	C-8
CANADA .....	C-8

---

AUSTRALIA/NEW ZEALAND .....	C-8
JAPAN .....	C-8
KOREA .....	C-8
TAIWAN .....	C-8