



Read Me First

for the HP Procurve Switch XL mini-GBIC Module

Software Release E.06.01 Is Now Available

Release E.06.01 of the software for the HP Procurve Series 5300XL Switches is now available from the HP Procurve website at:

<http://www.hp.com/go/hpprocurve>
(Click on **software | switches.**)

This release includes:

- Support for the Gigabit-LH mini-GBIC (J4860A) for use in the HP Procurve Switch XL mini-GBIC Module (J4878A)
- The addition of a Trace Route command
- The addition of 802.1x Open VLAN Mode -- a network security feature

and some other features and fixes to the software.

For HP Procurve 5300XL switches, which have software versions E.05.xx or earlier, you must first download the E.06.01, or later, version before you can use these features. This version of the software is currently only available on the HP Procurve web site.

Please see the section "Software Updates are *Free!*" on the next page for information about downloading the new software.

For a description of how to use these features, a complete listing of all the software changes, plus a listing of bug fixes and information on other topics, download the document *Release Notes: Version E.06.01 Software for the HP Procurve Series 5300XL Switches* (HP part number 5990-3056) from the HP Procurve website above. (Click on **technical support | manuals.**)

Software Updates Are *Free!*



Hewlett-Packard provides free software updates on the HP Procurve website for your Series 5300XL Switch. To access the software updates, go to the HP Procurve website at <http://www.hp.com/go/hpprocurve>, then click on **software** to go to the “Free Software Updates” page.

Register for Automatic Notification of Updates. From the “Free Software Updates” page you can also register yourself to automatically receive email notice of new updates for your managed Procurve networking products. Just follow the instructions on that page for how to receive the update notices.

To determine whether you have the latest software, you can compare the software version that is available on the website with the version that is currently installed on your switch. Follow the instructions below to determine the current software version on your switch.

To Determine the Current Software Version in Your Switch. For the Series 5300XL Switch, use any of the following methods to view the version:

- Start a console session with the switch. In the console login screen (the first screen displayed), the **Firmware revision** line under the switch name shows the software version.
- If you already have a console session going, at the prompt enter the **show version** command. The resulting display lists the current software version.
- In the web browser interface, click on the **Identity** tab. The current software version is listed as the **revision** number in the **Version** line.

To Download the New Software. Your HP Procurve Series 5300XL Switches support several different methods for downloading new software. For instructions on how to download the new software, please see appendix A, “File Transfers” in the *Management and Configuration Guide* on the *Documentation CD-ROM* included with your switch.

Mini-GBIC Operation Notes

Hot Swapping mini-GBICs. The Gigabit-SX, Gigabit-LX, and Gigabit-LH mini-GBICs that you can install in your HP Procurve Switch XL mini-GBIC Module can be removed and installed after the module is installed in the switch and receiving power. *Make sure you disconnect the network cables from the mini-GBICs before hot swapping them.*

When you replace a mini-GBIC with another mini-GBIC of a different type and then execute the **write memory** command in the switch console, the switch configures the port on the new mini-GBIC with the default mode (speed and duplex) settings used for new mini-GBIC type. The default mode for the Gigabit-SX, Gigabit-LX, and Gigabit-LH mini-GBICs is **Auto**. Note that the switch retains other port-specific configuration settings, such as trunking, Spanning Tree Protocol (STP), and VLAN values that were configured for the previous mini-GBIC.

Mini-GBIC Operation Notes (continued)

Connecting the mini-GBICs to Devices with Fixed Configurations. For some older network devices, including some older HP Procurve devices, the default for the Gigabit-SX, Gigabit-LX, and Gigabit-LH ports is a fixed configuration, for example 1000 Mbps/Full Duplex, or is otherwise different from these default configurations for the mini-GBICs, which is **Auto**. As a result, those devices may not connect properly to your mini-GBIC port; you will not get a link. Because of these default configuration and full-duplex considerations, for best operation, you should make sure that the devices connected to the mini-GBIC ports are also configured to **Auto**. *At a minimum, make sure the configurations match.*

Saving the Configuration After Installing or Exchanging a Module

The following cases automatically result in a change to the running-configuration on your switch:

- If you replace a module with another module of a different type and then reboot the switch
- If you install a module in a slot that has not previously been used (including when you install a module and apply power to the switch for the first time)
- If you replace a transceiver or mini-GBIC in a module with another transceiver or mini-GBIC of a different type.

If you want to save such changes to permanent memory (startup-configuration), use the **write memory** command in the switch console. This causes the switch to use the current hardware configuration after subsequent reboots. (The switch always reboots from the startup-configuration.)

If you do not save hardware changes to the startup-configuration, you will be prompted with the following message (to save the configuration) the next time you use the reboot or reload commands, or if you move from the CLI to the Menu interface in the switch console:

```
Do you want to save the current configuration [y/n] ?
```

Note that if you exchange module types in a slot and reboot the switch, but do not save the configuration, you can restore the switch to its prior configuration state by re-installing the original module type in the slot and rebooting the switch again. This is because the switch operates by using the running-config, but reboots from the startup-config.

Replacing a module with another module of the same type in the same slot does not affect the switch configuration and it is not necessary to save the configuration.

For more information on switch memory, including the startup-config and running-config memories, refer to the *Management and Configuration Guide* on the *Documentation CD-ROM* included with your switch. For the latest version of HP switch documentation, visit <http://www.hp.com/go/hpprocurve>. (Click on **technical support**, then **manuals**.)



© Hewlett-Packard Company 2001-2002. All rights reserved. Reproduction, adaptation, or translation without prior written permission is prohibited except as allowed under the copyright laws.

Technical information in this document is subject to change without notice.

Part Number: 5990-3054
August 2002
Product of Singapore

